



**LG**

Life's Good

North/Latin America  
Europe/Africa  
Asia/Oceania

Internal Use Only

<http://aic.lgservice.com>  
<http://eic.lgservice.com>  
<http://biz.lgservice.com>

# LED LCD TV

# SERVICE MANUAL

**CHASSIS : LD23E**

**MODEL : 72LM950V/W 72LM950V/W-ZA**

## CAUTION

BEFORE SERVICING THE CHASSIS,  
READ THE SAFETY PRECAUTIONS IN THIS MANUAL.



P/NO : MFL67361005 (1204-REV00)

Printed in Korea

# CONTENTS

<b>CONTENTS .....</b>	<b>2</b>
<b>SAFETY PRECAUTIONS .....</b>	<b>3</b>
<b>SERVICING PRECAUTIONS.....</b>	<b>4</b>
<b>SPECIFICATION .....</b>	<b>6</b>
<b>ADJUSTMENT INSTRUCTION .....</b>	<b>14</b>
<b>EXPLODED VIEW .....</b>	<b>23</b>
<b>SCHEMATIC CIRCUIT DIAGRAM .....</b>	

# SAFETY PRECAUTIONS

## IMPORTANT SAFETY NOTICE

Many electrical and mechanical parts in this chassis have special safety-related characteristics. These parts are identified by  $\triangle$  in the Schematic Diagram and Exploded View.

It is essential that these special safety parts should be replaced with the same components as recommended in this manual to prevent Shock, Fire, or other Hazards.

Do not modify the original design without permission of manufacturer.

### General Guidance

An **isolation Transformer should always be used** during the servicing of a receiver whose chassis is not isolated from the AC power line. Use a transformer of adequate power rating as this protects the technician from accidents resulting in personal injury from electrical shocks.

It will also protect the receiver and its components from being damaged by accidental shorts of the circuitry that may be inadvertently introduced during the service operation.

If any fuse (or Fusible Resistor) in this TV receiver is blown, replace it with the specified.

When replacing a high wattage resistor (Oxide Metal Film Resistor, over 1 W), keep the resistor 10 mm away from PCB.

Keep wires away from high voltage or high temperature parts.

### Before returning the receiver to the customer,

always perform an **AC leakage current check** on the exposed metallic parts of the cabinet, such as antennas, terminals, etc., to be sure the set is safe to operate without damage of electrical shock.

### Leakage Current Cold Check(Antenna Cold Check)

With the instrument AC plug removed from AC source, connect an electrical jumper across the two AC plug prongs. Place the AC switch in the on position, connect one lead of ohm-meter to the AC plug prongs tied together and touch other ohm-meter lead in turn to each exposed metallic parts such as antenna terminals, phone jacks, etc.

If the exposed metallic part has a return path to the chassis, the measured resistance should be between 1 M $\Omega$  and 5.2 M $\Omega$ .

When the exposed metal has no return path to the chassis the reading must be infinite.

An other abnormality exists that must be corrected before the receiver is returned to the customer.

### Leakage Current Hot Check (See below Figure)

Plug the AC cord directly into the AC outlet.

### Do not use a line Isolation Transformer during this check.

Connect 1.5 K / 10 watt resistor in parallel with a 0.15  $\mu$ F capacitor between a known good earth ground (Water Pipe, Conduit, etc.) and the exposed metallic parts.

Measure the AC voltage across the resistor using AC voltmeter with 1000 ohms/volt or more sensitivity.

Reverse plug the AC cord into the AC outlet and repeat AC voltage measurements for each exposed metallic part. Any voltage measured must not exceed 0.75 volt RMS which corresponds to 0.5 mA.

In case any measurement is out of the limits specified, there is possibility of shock hazard and the set must be checked and repaired before it is returned to the customer.

### Leakage Current Hot Check circuit



When 25A is impressed between Earth and 2nd Ground for 1 second, Resistance must be less than 0.1  $\Omega$

\*Base on Adjustment standard

# SERVICING PRECAUTIONS

**CAUTION:** Before servicing receivers covered by this service manual and its supplements and addenda, read and follow the **SAFETY PRECAUTIONS** on page 3 of this publication.  
**NOTE:** If unforeseen circumstances create conflict between the following servicing precautions and any of the safety precautions on page 3 of this publication, always follow the safety precautions. Remember: Safety First.

## General Servicing Precautions

1. Always unplug the receiver AC power cord from the AC power source before;
  - a. Removing or reinstalling any component, circuit board module or any other receiver assembly.
  - b. Disconnecting or reconnecting any receiver electrical plug or other electrical connection.
  - c. Connecting a test substitute in parallel with an electrolytic capacitor in the receiver.**CAUTION:** A wrong part substitution or incorrect polarity installation of electrolytic capacitors may result in an explosion hazard.
2. Test high voltage only by measuring it with an appropriate high voltage meter or other voltage measuring device (DVM, FETVOM, etc) equipped with a suitable high voltage probe. Do not test high voltage by "drawing an arc".
3. Do not spray chemicals on or near this receiver or any of its assemblies.
4. Unless specified otherwise in this service manual, clean electrical contacts only by applying the following mixture to the contacts with a pipe cleaner, cotton-tipped stick or comparable non-abrasive applicator; 10 % (by volume) Acetone and 90 % (by volume) isopropyl alcohol (90 % - 99 % strength)  
**CAUTION:** This is a flammable mixture.  
Unless specified otherwise in this service manual, lubrication of contacts is not required.
5. Do not defeat any plug/socket B+ voltage interlocks with which receivers covered by this service manual might be equipped.
6. Do not apply AC power to this instrument and/or any of its electrical assemblies unless all solid-state device heat sinks are correctly installed.
7. Always connect the test receiver ground lead to the receiver chassis ground before connecting the test receiver positive lead.  
Always remove the test receiver ground lead last.
8. Use with this receiver only the test fixtures specified in this service manual.  
**CAUTION:** Do not connect the test fixture ground strap to any heat sink in this receiver.

## Electrostatically Sensitive (ES) Devices

Some semiconductor (solid-state) devices can be damaged easily by static electricity. Such components commonly are called Electrostatically Sensitive (ES) Devices. Examples of typical ES devices are integrated circuits and some field-effect transistors and semiconductor "chip" components. The following techniques should be used to help reduce the incidence of component damage caused by static by static electricity.

1. Immediately before handling any semiconductor component or semiconductor-equipped assembly, drain off any electrostatic charge on your body by touching a known earth ground. Alternatively, obtain and wear a commercially available discharging wrist strap device, which should be removed to prevent potential shock reasons prior to applying power to the unit under test.

2. After removing an electrical assembly equipped with ES devices, place the assembly on a conductive surface such as aluminum foil, to prevent electrostatic charge buildup or exposure of the assembly.
3. Use only a grounded-tip soldering iron to solder or unsolder ES devices.
4. Use only an anti-static type solder removal device. Some solder removal devices not classified as "anti-static" can generate electrical charges sufficient to damage ES devices.
5. Do not use freon-propelled chemicals. These can generate electrical charges sufficient to damage ES devices.
6. Do not remove a replacement ES device from its protective package until immediately before you are ready to install it. (Most replacement ES devices are packaged with leads electrically shorted together by conductive foam, aluminum foil or comparable conductive material).
7. Immediately before removing the protective material from the leads of a replacement ES device, touch the protective material to the chassis or circuit assembly into which the device will be installed.  
**CAUTION:** Be sure no power is applied to the chassis or circuit, and observe all other safety precautions.
8. Minimize bodily motions when handling unpackaged replacement ES devices. (Otherwise harmless motion such as the brushing together of your clothes fabric or the lifting of your foot from a carpeted floor can generate static electricity sufficient to damage an ES device.)

## General Soldering Guidelines

1. Use a grounded-tip, low-wattage soldering iron and appropriate tip size and shape that will maintain tip temperature within the range of 500 °F to 600 °F.
2. Use an appropriate gauge of RMA resin-core solder composed of 60 parts tin/40 parts lead.
3. Keep the soldering iron tip clean and well tinned.
4. Thoroughly clean the surfaces to be soldered. Use a mall wire-bristle (0.5 inch, or 1.25 cm) brush with a metal handle. Do not use freon-propelled spray-on cleaners.
5. Use the following unsoldering technique
  - a. Allow the soldering iron tip to reach normal temperature. (500 °F to 600 °F)
  - b. Heat the component lead until the solder melts.
  - c. Quickly draw the melted solder with an anti-static, suction-type solder removal device or with solder braid.  
**CAUTION:** Work quickly to avoid overheating the circuit board printed foil.
6. Use the following soldering technique.
  - a. Allow the soldering iron tip to reach a normal temperature (500 °F to 600 °F)
  - b. First, hold the soldering iron tip and solder the strand against the component lead until the solder melts.
  - c. Quickly move the soldering iron tip to the junction of the component lead and the printed circuit foil, and hold it there only until the solder flows onto and around both the component lead and the foil.  
**CAUTION:** Work quickly to avoid overheating the circuit board printed foil.
  - d. Closely inspect the solder area and remove any excess or splashed solder with a small wire-bristle brush.



### IC Remove/Replacement

Some chassis circuit boards have slotted holes (oblong) through which the IC leads are inserted and then bent flat against the circuit foil. When holes are the slotted type, the following technique should be used to remove and replace the IC. When working with boards using the familiar round hole, use the standard technique as outlined in paragraphs 5 and 6 above.

#### Removal

1. Desolder and straighten each IC lead in one operation by gently prying up on the lead with the soldering iron tip as the solder melts.
2. Draw away the melted solder with an anti-static suction-type solder removal device (or with solder braid) before removing the IC.

#### Replacement

1. Carefully insert the replacement IC in the circuit board.
2. Carefully bend each IC lead against the circuit foil pad and solder it.
3. Clean the soldered areas with a small wire-bristle brush. (It is not necessary to reapply acrylic coating to the areas).

### "Small-Signal" Discrete Transistor

#### Removal/Replacement

1. Remove the defective transistor by clipping its leads as close as possible to the component body.
2. Bend into a "U" shape the end of each of three leads remaining on the circuit board.
3. Bend into a "U" shape the replacement transistor leads.
4. Connect the replacement transistor leads to the corresponding leads extending from the circuit board and crimp the "U" with long nose pliers to insure metal to metal contact then solder each connection.

### Power Output, Transistor Device

#### Removal/Replacement

1. Heat and remove all solder from around the transistor leads.
2. Remove the heat sink mounting screw (if so equipped).
3. Carefully remove the transistor from the heat sink of the circuit board.
4. Insert new transistor in the circuit board.
5. Solder each transistor lead, and clip off excess lead.
6. Replace heat sink.

### Diode Removal/Replacement

1. Remove defective diode by clipping its leads as close as possible to diode body.
2. Bend the two remaining leads perpendicular y to the circuit board.
3. Observing diode polarity, wrap each lead of the new diode around the corresponding lead on the circuit board.
4. Securely crimp each connection and solder it.
5. Inspect (on the circuit board copper side) the solder joints of the two "original" leads. If they are not shiny, reheat them and if necessary, apply additional solder.

### Fuse and Conventional Resistor

#### Removal/Replacement

1. Clip each fuse or resistor lead at top of the circuit board hollow stake.
2. Securely crimp the leads of replacement component around notch at stake top.

3. Solder the connections.

**CAUTION:** Maintain original spacing between the replaced component and adjacent components and the circuit board to prevent excessive component temperatures.

### Circuit Board Foil Repair

Excessive heat applied to the copper foil of any printed circuit board will weaken the adhesive that bonds the foil to the circuit board causing the foil to separate from or "lift-off" the board. The following guidelines and procedures should be followed whenever this condition is encountered.

#### At IC Connections

To repair a defective copper pattern at IC connections use the following procedure to install a jumper wire on the copper pattern side of the circuit board. (Use this technique only on IC connections).

1. Carefully remove the damaged copper pattern with a sharp knife. (Remove only as much copper as absolutely necessary).
2. Carefully scratch away the solder resist and acrylic coating (if used) from the end of the remaining copper pattern.
3. Bend a small "U" in one end of a small gauge jumper wire and carefully crimp it around the IC pin. Solder the IC connection.
4. Route the jumper wire along the path of the out-away copper pattern and let it overlap the previously scraped end of the good copper pattern. Solder the overlapped area and clip off any excess jumper wire.

#### At Other Connections

Use the following technique to repair the defective copper pattern at connections other than IC Pins. This technique involves the installation of a jumper wire on the component side of the circuit board.

1. Remove the defective copper pattern with a sharp knife. Remove at least 1/4 inch of copper, to ensure that a hazardous condition will not exist if the jumper wire opens.
2. Trace along the copper pattern from both sides of the pattern break and locate the nearest component that is directly connected to the affected copper pattern.
3. Connect insulated 20-gauge jumper wire from the lead of the nearest component on one side of the pattern break to the lead of the nearest component on the other side.

Carefully crimp and solder the connections.

**CAUTION:** Be sure the insulated jumper wire is dressed so the it does not touch components or sharp edges.

# SPECIFICATION

NOTE : Specifications and others are subject to change without notice for improvement.

## 1. Application range

This specification is applied to the LCD TV used LD23E chassis.

## 2. Requirement for Test

Each part is tested as below without special appointment.

- 1) Temperature: 25 °C ± 5 °C(77 °F ± 9 °F), CST: 40 °C ± 5 °C
- 2) Relative Humidity: 65 % ± 10 %
- 3) Power Voltage
  - : Standard input voltage (AC 100-240 V~, 50/60 Hz)
  - \* Standard Voltage of each products is marked by models.
- 4) Specification and performance of each parts are followed each drawing and specification by part number in accordance with BOM.
- 5) The receiver must be operated for about 20 minutes prior to the adjustment.

## 3. Test method

- 1) Performance: LGE TV test method followed
- 2) Demanded other specification
  - Safety : CE, IEC specification
  - EMC : CE, IEC
  - Wireless : Wireless HD Specification (Option)

## 4. Model General Specification

No.	Item	Specification	Remarks
1	Market	EU(PAL Market-36Countries)	<b>DTV &amp; Analog (Total 37 countries)</b> <b>DTV(MPEG2/4,DVB-T/T2/S)</b> Albania/Austria/Belarus/Belgium/Bosnia/Bulgaria/Croatia/Czech/Estonia/France/Germany/Greece/Hungary/Ireland/Italy/Kazakhstan/Latvia/Lithuania/Luxembourg/Morocco/Netherlands/Poland/Portugal/Romania/Russia/Serbia/Slovenia/Spain/Slovakia/Switzerland/Turkey/UK/Ukraine/Denmark/Finland/Norway/Sweden  <b>Supported satellite : 29 satellites</b> ABS1 75.0E/ AMOS 4.0W/ ASIASATS 105.5E/ ASTRA1L-HMKR 19.2E/ ASTRA2ABD 28.2E/ ASTRA3AB 23.5E/ ASTRA4A 4.8E/ ATLANTICBIRD2 8.0W/ ATLANTICBIRD3 5.0W/ BADR 26.0E/ EUROBIRD3 33.0E/ EUROBIRD9A 9.0E/ EUTELSATW2A 10.E/ EUTELSATW3A 7.0E/ EUTEL-SATW4W7 36.0E/ EUTELSESAT 16.0E/ EXPRESSAM1 40.0E/ EXPRESAM3 140.0E/ EXPRESSAM33 96.5E/ HEL-LASAT2 39.0E/ HISPASAT1CDE 30.0W/ HOTBIRD 13.0E/ INTELSAT10&7 68.5E/ INTELSAT15 85.2E/ INTELSAT904 60.0E/ NILESAT 7.0W/ THOR 0.8W/ TURKSAT 42.0E/ YAMAL201 90.0E
2	Broadcasting system	1) PAL-BG 2) PAL-DK 3) PAL-I/I' 4) SECAM L/L', DK, BG, I 5) DVB-T 6) DVB-C 7) DVB-T2 8) DVB-S 9) DVB-S2	DVB-S: Satellite

No.	Item	Specification	Remarks
3	Receiving system	Analog : Upper Heterodyne Digital : COFDM, QAM	<p>► DVB-T</p> <ul style="list-style-type: none"> <li>- Guard Interval(Bitrate_Mbit/s) 1/4, 1/8, 1/16, 1/32</li> <li>- Modulation : Code Rate QPSK : 1/2, 2/3, 3/4, 5/6, 7/8 16-QAM : 1/2, 2/3, 3/4, 5/6, 7/8 64-QAM : 1/2, 2/3, 3/4, 5/6, 7/8</li> </ul> <p>► DVB-T2</p> <ul style="list-style-type: none"> <li>- Guard Interval(Bitrate_Mbit/s) 1/4, 1/8, 1/16, 1/32, 1/128, 19/128, 19/256,</li> <li>- Modulation : Code Rate QPSK : 1/2, 2/5, 2/3, 3/4, 5/6 16-QAM : 1/2, 2/5, 2/3, 3/4, 5/6 64-QAM : 1/2, 2/5, 2/3, 3/4, 5/6 256-QAM : 1/2, 2/5, 2/3, 3/4, 5/6</li> </ul> <p>► DVB-C</p> <ul style="list-style-type: none"> <li>- Symbolrate : 4.0Msymbols/s to 7.2Msymbols/s</li> <li>- Modulation : 16QAM, 64-QAM, 128-QAM and 256-QAM</li> </ul> <p>► DVB-S/S2</p> <ul style="list-style-type: none"> <li>- symbolrate DVB-S2 (8PSK / QPSK) : 2 ~ 45Msymbol/s DVB-S (QPSK) : 2 ~ 45Msymbol/s</li> <li>- viterbi DVB-S mode : 1/2, 2/3, 3/4, 5/6, 7/8 DVB-S2 mode : 1/2, 2/3, 3/4, 3/5, 4/5, 5/6, 8/9, 9/10</li> </ul>
4	Input Voltage	AC 100 ~ 240V 50/60Hz	
5	Screen Size	46.96 inches	1046.68(H) x 594.02(V) x 1.5(D)mm (Typ.) FHD+240Hz
6	Aspect Ratio	16:9	
7	Tuning System		
8	Operating Environment	1) Temp : 0 ~ 40 deg 2) Humidity : ~ 80 %	
9	Storage Environment	1) Temp : -20 ~ 60 deg 2) Humidity : ~ 85 %	

## 5. Component Video Input (Y, CB/PB, CR/PR)

No.	Resolution	H-freq(kHz)	V-freq(Hz)	Pixel clock
1.	720×480	15.73	60.00	SDTV, DVD 480i
2.	720×480	15.63	59.94	SDTV, DVD 480i
3.	720×480	31.47	59.94	480p
4.	720×480	31.50	60.00	480p
5.	720×576	15.625	50.00	SDTV 576i
6.	720×576	31.25	50.00	SDTV 576p
7.	1280×720	45.00	50.00	HDTV 720p
8.	1280×720	44.96	59.94	HDTV 720p
9.	1280×720	45.00	60.00	HDTV 720p
10.	1920×1080	31.25	50.00	HDTV 1080i
11.	1920×1080	33.75	60.00	HDTV 1080i
12.	1920×1080	33.72	59.94	HDTV 1080i
13.	1920×1080	56.250	50	HDTV 1080p
14.	1920×1080	67.5	60	HDTV 1080p

## 6. RGB input (PC)

No.	Resolution	H-freq(kHz)	V-freq.(Hz)	Pixel clock(MHz)	Proposed	
	PC					DDC
1	640*350	31.468	70.09	25.17	EGA	X
2	720*400	31.469	70.08	28.32	DOS	O
3	640*480	31.469	59.94	25.17	VESA(VGA)	O
4	800*600	37.879	60.31	40.00	VESA(SVGA)	O
5	1024*768	48.363	60.00	65.00	VESA(XGA)	O
6	1152*864	54.348	60.053	80	VESA(WXGA)	X
7	1360*768	47.712	60.015	85.5	WUXGA	O
8	1920*1080	67.5	60.00	148.5	WUXGA(CEA861D)	O

## 7. HDMI Input

No.	Resolution	H-freq(kHz)	V-freq.(Hz)	Pixel clock(MHz)	VIC	Proposed	
<b>HDMI-PC</b>							DDC
1	720*400	31.468	70.08	28.321			X
2	640*480	31.469	59.94	25.17		VESA	O
3	800*600	37.879	60.31	40.00		VESA	O
4	1024*768	48.363	60.00	65.00		VESA(XGA)	O
5	1360*768	47.72	59.8	84.75		WXGA	O
6	1280*1024	63.595	60.0	108.875		SXGA	O
7	1920*1080	67.5	60.00	148.5		WUXGA	O
8	1360*768	47.712	60.015	85.5		VESA(WXGA)	O
9	1920*1080	67.5	60.00	148.5		WUXGA(CEA861D)	O
<b>HDMI-DTV</b>							
1	640*480	31.469 / 31.5	59.94/ 60	25.125	1	SDTV 480P	
2	720*480	31.469 / 31.5	59.94 / 60	27.00/27.03	2,3	SDTV 480P	
3	720*576	31.25	50	27	17,18	SDTV 576P	
4	720*576	15.625	50	27	21	SDTV 576I	
5	1280*720	37.500	50	74.25	19	HDTV 720P	
6	1280*720	44.96 / 45	59.94 / 60	74.17/74.25	4	HDTV 720P	
7	1920*1080	33.72 / 33.75	59.94 / 60	74.17/74.25	5	HDTV 1080I	
8	1920*1080	28.125	50.00	74.25	20	HDTV 1080I	
9	1920*1080	26.97 / 27	23.97 / 24	74.17/74.25	32	HDTV 1080P	
10	1920*1080		25		33	HDTV 1080P	
11	1920*1080	33.716 / 33.75	29.976 / 30.00	74.25	34	HDTV 1080P	
12	1920*1080	56.250	50	148.5	31	HDTV 1080P	
13	1920*1080	67.43 / 67.5	59.94 / 60	148.35/148.50	16	HDTV 1080P	

## 8. 3D Mode

### 8.1. RF Input(3D supported mode manually)

No.	Resolution	Proposed	3D input proposed mode
1	HD	1080I 720P	2D to 3D Side by Side(Half) Top & Bottom
2	SD	576P 576I	2D to 3D

### 8.2. RF Input(3D supported mode automatically)

No.	Signal	3D input proposed mode
1	Frame Compatible	Side by Side(Half), Top & Bottom

## 8.3. HDMI Input

### 8.3.1. HDMI 1.3 (3D supported mode manually)

No.	Resolution	H-freq(kHz)	V-freq.(kHz)	Pixel clock(MHz)	Proposed	3D input proposed mode
1	1280*720	45.00	60.00	74.25	HDTV 720P	2D to 3D Side by Side(half), Top & Bottom, Single Frame Sequential
2	1280*720	37.500	50	74.25	HDTV 720P	2D to 3D Side by Side(half), Top & Bottom, Single Frame Sequential
3	1920*1080	33.75	60.00	74.25	HDTV 1080I	2D to 3D Side by Side(half), Top & Bottom
4	1920*1080	28.125	50.00	74.25	HDTV 1080I	2D to 3D Side by Side(half), Top & Bottom
5	1920*1080	27.00	24.00	74.25	HDTV 1080P	2D to 3D Side by Side(half), Top & Bottom
6	1920*1080	28.12	25	74.25	HDTV 1080P	2D to 3D Side by Side(half), Top & Bottom, Checkerboard
7	1920*1080	33.75	30.00	74.25	HDTV 1080P	2D to 3D Side by Side(half), Top & Bottom, Checkerboard
8	1920*1080	56.25	50	148.5	HDTV 1080P	2D to 3D Side by Side(half), Top & Bottom, Checkerboard, Single Frame Sequential, Row Interleaving, Column Interleaving
9	1920*1080	67.50	60.00	148.5	HDTV 1080P	2D to 3D Side by Side(half), Top & Bottom, Checkerboard, Single Frame Sequential, Row Interleaving, Column Interleaving

### 8.3.2. HDMI 1.4b (3D supported mode automatically)

No.	Resolution	H-freq(kHz)	V-freq.(Hz)	Pixel clock(MHz)	VIC	3D input proposed mode	Proposed
1	640*480	31.469 / 31.5	59.94/ 60	25.125	1	Top-and-Bottom Side-by-side(half)	Secondary(SDTV 480P) Secondary(SDTV 480P)
2		62.938/63	59.94/ 60	50.35/50.4	1	Frame packing Line alternative	Secondary(SDTV 480P) (SDTV 480P)
3		31.469 / 31.5	59.94/ 60	50.35/50.4	1	Side-by-side(Full)	(SDTV 480P)
4	720*480	31.469 / 31.5	59.94 / 60	27.00/27.03	2,3	Top-and-Bottom Side-by-side(half)	Secondary(SDTV 480P) Secondary(SDTV 480P)
5		62.938/63	59.94 / 60	54/54.06	2,3	Frame packing Line alternative	Secondary(SDTV 480P) (SDTV 480P)
6		31.469 / 31.5	59.94 / 60	54/54.06	2,3	Side-by-side(Full)	(SDTV 480P)
7	720*576	31.25	50	27	17,18	Top-and-Bottom Side-by-side(half)	Secondary(SDTV 576P) Secondary(SDTV 576P)
8		62.5	50	54	17,18	Frame packing Line alternative	Secondary(SDTV 576P) (SDTV 576P)
9		31.25	50	54	17,18	Side-by-side(Full)	(SDTV 576P)
10	720*576	15.625	50	27	21	Top-and-Bottom Side-by-side(half)	Secondary(SDTV 576I) Secondary(SDTV 576I)
11		31.25	50	54	21	Frame packing Field alternative	Secondary(SDTV 576I) (SDTV 576I)
12		15.625	50	54	21	Side-by-side(Full)	(SDTV 576I)
13	1280*720	37.500	50	74.25	19	Top-and-Bottom Side-by-side(half)	Primary(HDTV 720P) Primary(HDTV 720P)
14		75	50	148.5	19	Frame packing Line alternative	Primary(HDTV 720P) (HDTV 720P)
15		37.500	50	148.5	19	Side-by-side(Full)	(HDTV 720P)
16		44.96 / 45	59.94 / 60	74.18/74.25	4	Top-and-Bottom Side-by-side(half)	Primary(HDTV 720P) Primary(HDTV 720P)
17		89.91/90	59.94 / 60	148.35/148.5	4	Frame packing Line alternative	Primary(HDTV 720P) (HDTV 720P)
18		44.96 / 45	59.94 / 60	148.35/148.5	4	Side-by-side(Full)	(HDTV 720P)
19	1920*1080	33.72 / 33.75	59.94 / 60	74.17/74.25	5	Top-and-Bottom Side-by-side(half)	Secondary(HDTV 1080I) Primary(HDTV 1080I)
20		67.432/67.50	59.94 / 60	148.35/148.5	5	Frame packing Field alternative	Primary(HDTV 1080I) (HDTV 1080I)
21		33.72 / 33.75	59.94 / 60	148.35/148.5	5	Side-by-side(Full)	(HDTV 1080I)
22		28.125	50.00	74.25	20	Top-and-Bottom Side-by-side(half)	Secondary(HDTV 1080I) Primary(HDTV 1080I)
23		56.25	50.00	148.5	20	Frame packing Field alternative	Primary(HDTV 1080I) (HDTV 1080I)
24		28.125	50.00	74.25	20	Side-by-side(Full)	(HDTV 1080I)
25	1920*1080	26.97 / 27	23.97 / 24	74.18/74.25	32	Top-and-Bottom Side-by-side(half)	Primary(HDTV 1080P) Primary(HDTV 1080P)
26		43.94/54	23.97 / 24	148.35/148.5	32	Frame packing Line alternative	Primary(HDTV 1080P) (HDTV 1080P)
27		26.97 / 27	23.97 / 24	148.35/148.5	32	Side-by-side(Full)	(HDTV 1080P)
28		28.12	25	74.25	33	Top-and-Bottom Side-by-side(half)	Secondary(HDTV 1080P) Secondary(HDTV 1080P)
29		56.24	25	148.5	33	Frame packing Line alternative	Secondary(HDTV 1080P) (HDTV 1080P)
30		28.12	25	148.5	33	Side-by-side(Full)	(HDTV 1080P)
31		33.716 / 33.75	29.976 / 30.00	74.18/74.25	34	Top-and-Bottom Side-by-side(half)	Primary(HDTV 1080P) Secondary(HDTV 1080P)
32		67.432 / 67.5	29.976 / 30.00	148.35/148.5	34	Frame packing Line alternative	Primary(HDTV 1080P) (HDTV 1080P)
33		33.716 / 33.75	29.976 / 30.00	148.35/148.5	34	Side-by-side(Full)	(HDTV 1080P)
34		56.250	50	148.5	31	Top-and-Bottom Side-by-side(half)	Primary(HDTV 1080P) Secondary(HDTV 1080P)
35		67.43 / 67.5	59.94 / 60	148.35/148.50	16	Top-and-Bottom Side-by-side(half)	Primary(HDTV 1080P) Secondary(HDTV 1080P)

#### 8.4. HDMI-PC Input (3D) (3D supported mode manually)

No.	Resolution	H-freq(kHz)	V-freq.(Hz)	Pixel clock(MHz)	3D input proposed mode	Proposed
1	1024*768	48.36	60	65	2D to 3D, Side by Side(half) Top & Bottom	HDTV 768P
2	1360*768	47.71	60	85.5	2D to 3D, Side by Side(half) Top & Bottom	HDTV 768P
3	1920*1080	67.500	60	148.50	2D to 3D, Side by Side(half) Top & Bottom, Checker Board, Single Frame Sequential, Row Interleaving, Column Interleaving	HDTV 1080P
4	Others	-	-	-	2D to 3D	640*350 720*400 640*480 800*600 1152*864

#### 8.5. RGB-PC Input (3D) (3D supported mode manually)

No.	Resolution	H-freq(kHz)	V-freq.(Hz)	Pixel clock(MHz)	3D input proposed mode	Proposed
1	1024*768	48.36	60	65	2D to 3D, Side by Side(half) Top & Bottom	HDTV 768P
2	1360*768	47.71	60	85.5	2D to 3D, Side by Side(half) Top & Bottom	HDTV 768P
3	1920*1080	67.500	60	148.50	2D to 3D, Side by Side(half) Top & Bottom,	HDTV 1080P
4	Others	-	-	-	2D to 3D	640*350 720*400 640*480 800*600 1152*864 1280*1024

#### 8.6. Component Input(3D) (3D supported mode manually)

No.	Resolution	H-freq(kHz)	V-freq.(Hz)	Pixel clock	3D input proposed mode	Proposed
1	1280*720	37.5	50	74.25	2D to 3D, Side by Side, Top & Bottom	HDTV 720P
2	1280*720	45.00	60.00	74.25	2D to 3D, Side by Side, Top & Bottom	HDTV 720P
3	1280*720	44.96	59.94	74.176	2D to 3D, Side by Side, Top & Bottom	HDTV 720P
4	1920*1080	33.75	60.00	74.25	2D to 3D, Side by Side, Top & Bottom	HDTV 1080I
5	1920*1080	33.72	59.94	74.176	2D to 3D, Side by Side, Top & Bottom	HDTV 1080I
6	1920*1080	28.12	50	74.25	2D to 3D, Side by Side, Top & Bottom	HDTV 1080I
7	1920*1080	67.500	60	148.50	2D to 3D, Side by Side, Top & Bottom	HDTV 1080P
8	1920*1080	67.432	59.94	148.352	2D to 3D, Side by Side, Top & Bottom	HDTV 1080P
9	1920*1080	27.000	24.000	74.25	2D to 3D, Side by Side, Top & Bottom	HDTV 1080P
10	1920*1080	28.12	25	74.25	2D to 3D, Side by Side, Top & Bottom	HDTV 1080P
11	1920*1080	56.25	50	74.25	2D to 3D, Side by Side, Top & Bottom	HDTV 1080P
12	1920*1080	26.97	23.976	74.176	2D to 3D, Side by Side, Top & Bottom	HDTV 1080P
13	1920*1080	33.75	30.000	74.25	2D to 3D, Side by Side, Top & Bottom	HDTV 1080P
14	1920*1080	33.71	29.97	74.176	2D to 3D, Side by Side, Top & Bottom	HDTV 1080P



### 8.7. USB Input(3D) (3D supported mode manually)

No.	Resolution	H-freq(kHz)	V-freq.(Hz)	Pixel clock(MHz)	3D input proposed mode	Proposed
1	1920*1080	33.75	30	74.25	2D to 3D, Side by Side(Half), Top & Bottom, Checkerboard, Row Interleaving, Column Interleaving (Photo : side by Side(half), Top & Bottom)	HDTV 1080P

### 8.8. USB Input(3D) (3D supported mode automatically)

No.	Resolution	H-freq(kHz)	V-freq.(Hz)	Pixel clock(MHz)	3D input proposed mode	Proposed
1	1920*1080	33.75	30	74.25	Side by Side(Half), Top & Bottom, Checkerboard, MPO(photo)	HDTV 1080P








### 8.9. DLNA Input (3D) (3D supported mode manually)

No.	Resolution	H-freq(kHz)	V-freq.(Hz)	Pixel clock(MHz)	3D input proposed mode	Proposed
1	1920*1080	33.75	30	74.25	2D to 3D, Side by Side(Half), Top & Bottom, Checkerboard, Row Interleaving, Column Interleaving (Photo : side by Side(half), Top & Bottom)	HDTV 1080P

### 8.10. DLNA Input (3D) (3D supported mode automatically)

No.	Resolution	H-freq(kHz)	V-freq.(Hz)	Pixel clock(MHz)	3D input proposed mode	Proposed
1	1920*1080	33.75	30	74.25	Side by Side(Half), Top & Bottom, Checkerboard, MPO(photo)	HDTV 1080P

■ Remark: 3D Input mode

No.	Side by Side	Top & Bottom	Checker board	Single Frame Sequential	Frame Packing	Line Interleaving	Column Interleaving
1							

# ADJUSTMENT INSTRUCTION

## 1. Application Range

This specification sheet is applied to all of the LED LCD TV with LD23E chassis.

## 2. Designation

- (1) Because this is not a hot chassis, it is not necessary to use an isolation transformer. However, the use of isolation transformer will help protect test instrument.
- (2) Adjustment must be done in the correct order.
- (3) The adjustment must be performed in the circumstance of  $25^{\circ}\text{C} \pm 5^{\circ}\text{C}$  of temperature and  $65\% \pm 10\%$  of relative humidity if there is no specific designation.
- (4) The input voltage of the receiver must keep AC 100-240 V~, 50/60 Hz.
- (5) The receiver must be operated for about 5 minutes prior to the adjustment when module is in the circumstance of over 15.

In case of keeping module is in the circumstance of  $0^{\circ}\text{C}$ , it should be placed in the circumstance of above  $15^{\circ}\text{C}$  for 2 hours.

In case of keeping module is in the circumstance of below  $-20^{\circ}\text{C}$ , it should be placed in the circumstance of above  $15^{\circ}\text{C}$  for 3 hours.

### [Caution]

When still image is displayed for a period of 20 minutes or longer (Especially where W/B scale is strong. Digital pattern 13ch and/or Cross hatch pattern 09ch), there can some afterimage in the black level area.

## 3. Automatic Adjustment


### 3.1. ADC Adjustment

#### 3.1.1. Overview

ADC adjustment is needed to find the optimum black level and gain in Analog-to-Digital device and to compensate RGB deviation.

#### 3.1.2. Equipment & Condition

- (1) USB to RS-232C Jig
- (2) MSPG-925 Series Pattern Generator(MSPG-925FA, pattern - 65)
  - Resolution : 480i Comp1  
1080P Comp1  
1920\*1080 RGB
  - Pattern : Horizontal 100% Color Bar Pattern
  - Pattern level :  $0.7 \pm 0.1$  Vp-p
  - Image



#### 3.1.3. Adjustment

- (1) Adjustment method
  - Using RS-232, adjust items in the other shown in "3.1.3.3"

#### (2) Adj. protocol

Protocol	Command	Set ACK
Enter adj. mode	aa 00 00	a 00 OK00x
Source change	xb 00 04 xb 00 06	b 00 OK04x (Adjust 480i, 1080p Comp1 ) b 00 OK06x (Adjust 1920*1080 RGB)
Begin adj.	ad 00 10	
Return adj. result		OKx (Case of Success) NGx (Case of Fail)
Read adj. data	(main) ad 00 20 (sub ) ad 00 21	(main) 000000000000000000000000000000007c007b006dx (Sub) 000000070000000000000000000000007c00830077x
Confirm adj.	ad 00 99	NG 03 00x (Fail) NG 03 01x (Fail) NG 03 02x (Fail) OK 03 03x (Success)
End adj.	aa 00 90	a 00 OK90x


Ref.) ADC Adj. RS232C Protocol\_Ver1.0

#### (3) Adj. order


- aa 00 00 [Enter ADC adj. mode]
- xb 00 04 [Change input source to Component1 (480i& 1080p)]
- ad 00 10 [Adjust 480i&1080p Comp1]
- xb 00 06 [Change input source to RGB(1024\*768)]
- ad 00 10 [Adjust 1920\*1080 RGB]
- ad 00 90 End adj.

## 3.2. MAC address D/L, CI+ key D/L, Widevine key D/L

Connect: PCBA Jig → RS-232C Port== PC → RS-232C Port  
Communication Prot connection




- Com 1,2,3,4 and 115200(Baudrate)  
Mode check: Online Only
- Check the test process: DETECT → MAC → CI → Widevine → ESN
- Play: START
- Result: Ready, Test, OK or NG
- Printer Out (MAC Address Label)



### 3.3. LAN Inspection


#### 3.3.1. Equipment & Condition

- Each other connection to LAN Port of IP Hub and Jig




#### 3.3.2. LAN inspection solution

- LAN Port connection with PCB
- Network setting at MENU Mode of TV
- Setting automatic IP
- Setting state confirmation
  - If automatic setting is finished, you confirm IP and MAC Address.



#### 3.3.3. WIDEVINE key Inspection

- Confirm key input data at the "IN START" MENU Mode.



### 3.4. LAN PORT INSPECTION(PING TEST)

Connect SET → LAN port == PC → LAN Port




#### 3.4.1. Equipment setting

- Play the LAN Port Test PROGRAM.
- Input IP set up for an inspection to Test Program.
  - \*IP Number : 12.12.2.2

#### 3.4.2. LAN PORT inspection(PING TEST)

- Play the LAN Port Test Program.
- Connect each other LAN Port Jack.
- Play Test (F9) button and confirm OK Message.
- Remove LAN cable.



### 3.5. Model name & Serial number Download

#### 3.5.1. Model name & Serial number D/L


- Press "Power on" key of service remote control. (Baud rate : 115200 bps)
- Connect RS232 Signal Cable to RS-232 Jack.
- Write Serial number by use RS-232.
- Must check the serial number at Instant menu.

#### 3.5.2. Method & notice

- Serial number D/L is using of scan equipment.
- Setting of scan equipment operated by Manufacturing Technology Group.
- Serial number D/L must be conformed when it is produced in production line, because serial number D/L is mandatory by D-book 4.0.

\* Manual Download (Model Name and Serial Number)  
If the TV set is downloaded by OTA or service man, sometimes model name or serial number is initialized.(Not always)  
It is impossible to download by bar code scan, so It need Manual download.

- 1) Press the "Instart" key of Adjustment remote control.
- 2) Go to the menu "7.Model Number D/L" like below photo.
- 3) Input the Factory model name(ex 42LD450-TA) or Serial number like photo.



- 4) Check the model name Instart menu. → Factory name displayed. (ex 47LM960V-ZB)
- 5) Check the Diagnostics.(DTV country only) → Buyer model displayed. (ex 47LM960V-ZB)

### 3.6. CI+ Key checking method

- Check the Section 4.2

Check whether the key was downloaded or not at 'In Start' menu. (Refer to below).



=> Check the Download to CI+ Key value in LGset.

#### 3.6.1. Check the method of CI+ Key value

- (1) Check the method on Instart menu
- (2) Check the method of RS232C Command

1) Into the main ass'y mode(RS232: aa 00 00)

CMD 1	CMD 2	Data 0
A	A	0 0

2) Check the key download for transmitted command (RS232: ci 00 10)

CMD 1	CMD 2	Data 0
C	I	1 0

3) Result value

- Normally status for download : OKx
- Abnormally status for download : NGx

#### 3.6.2. Check the method of CI+ key value(RS232)

1) Into the main ass'y mode(RS232: aa 00 00)

CMD 1	CMD 2	Data 0
A	A	0 0

2) Check the method of CI+ key by command (RS232: ci 00 20)

CMD 1	CMD 2	Data 0
C	I	2 0

3) Result value

i 01 OK 1d1852d21c1ed5dcx


→ CI+ Key Value

### 3.7. WIFI MAC ADDRESS CHECK

(1) Using RS232 Command

	H-freq(kHz)	V-freq.(Hz)
Transmission	[A][I][ ][Set ID][ ][20][Cr]	[O][K][X] or [NG]

(2) Check the menu on in-start





## 4. Manual Adjustment

\* ADC adjustment is not needed because of OTP(Auto ADC adjustment)

### 4.1 EDID(The Extended Display Identification Data)/DDC(Display Data Channel) download

#### 4.1.1. Overview

It is a VESA regulation. A PC or a MNT will display an optimal resolution through information sharing without any necessity of user input. It is a realization of "Plug and Play".

#### 4.1.2. Equipment

- Since embedded EDID data is used, EDID download JIG, HDMI cable and D-sub cable are not need.
- Adjustment remote control

#### 4.1.3. Download method

- (1) Press "ADJ" key on the Adjustment remote control then select "10.EDID D/L", By pressing "Enter" key, enter EDID D/L menu.
- (2) Select "Start" button by pressing "Enter" key, HDMI1/ HDMI2/ HDMI3/ HDMI4/ RGB are writing and display OK or NG.



#### 4.1.4. EDID DATA

• HDMI(FHD 3D, HDMI 1.4a, 3D)

	0x00	0x01	0x02	0x03	0x04	0x05	0x06	0x07	0x08	0x09	0x0A	0x0B	0x0C	0x0D	0x0E	0x0F
0x00	00	FF	FF	FF	FF	FF	FF	00	1E	6D	(a)(d)		(b)			
0x01	(c)		01	03	80	A0	5A	78	0A	EE	91	A3	54	4C	99	26
0x02	0F	50	54	A1	08	00	71	40	81	C0	81	00	81	80	95	00
0x03	90	40	A9	C0	B3	00	02	3A	80	18	71	38	2D	40	58	2C
0x04	45	00	A0	5A	00	00	00	1E	66	21	50	B0	51	00	1B	30
0x05	40	70	36	00	A0	5A	00	00	1E	00	00	00	FD	00	00	39
0x06	3F	1F	52	10	00	0A	20	20	20	20	20	20	(d)			
0x07	(d)														01	(e)1
0x08	02	03	37	F1	4E	90	1F	04	13	05	14	03	02	12	20	21
0x09	22	15	01	26	15	07	50	09	57	07	(f)					
0x0A	(f)															
0x0B	(f)			E3	05	03	01	02	3A	80	18	71	1C	38	2D	40
0x0C	2C	45	00	A0	5A	00	00	00	1E	01	1D	80	18	71	1C	16
0x0D	20	58	2C	25	00	A0	5A	00	00	00	9E	01	1D	00	72	51
0x0E	D0	1E	20	6E	28	55	00	A0	5A	00	00	00	1E	00	00	00
0x0F	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	(e)2

• RGB

	0x00	0x01	0x02	0x03	0x04	0x05	0x06	0x07	0x08	0x09	0x0A	0x0B	0x0C	0x0D	0x0E	0x0F
0x00	00	FF	FF	FF	FF	FF	FF	00	1E	6D	(a)		(b)			
0x01	(c)		01	03	80	10	09	78	0A	EE	91	A3	54	4C	99	26
0x02	0F	50	54	A1	08	00	71	40	81	C0	81	00	81	80	95	00
0x03	90	40	A9	C0	B3	00	02	3A	80	18	71	38	2D	40	58	2C
0x04	45	00	A0	5A	00	00	00	1E	66	21	50	B0	51	00	1B	30
0x05	40	70	36	00	A0	5A	00	00	1E	00	00	00	FD	00	00	3A
0x06	3E	1E	53	10	00	0A	20	20	20	20	20	20	(d)			
0x07	(d)														00	(e)3

• Reference

- HDMI1 ~ HDMI4 / RGB
- In the data of EDID, bellows may be different by S/W or Input mode.

(a) Product ID

(b) Serial No: Controlled on production line.

(c) Month, Year: Controlled on production line:

ex) Monthly : '01' → '01'

Year : '2012' → '16'

(d) Model Name(Hex): LGTV

(e) Checksum(LG TV): Changeable by total EDID data.

(f) Vendor Specific(HDMI)

# HDMI 1(C/S : 9D BA)

EDID Block 0, Bytes 0-127 [00H-7FH]

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
00	00	FF	FF	FF	FF	FF	FF	00	1E	6D	01	00	01	01	01	01
10	01	16	01	03	80	A0	5A	78	0A	EE	91	A3	54	4C	99	26
20	0F	50	54	A1	08	00	31	40	45	40	61	40	71	40	81	80
30	01	01	01	01	01	01	02	3A	80	18	71	38	2D	40	58	2C
40	45	00	A0	5A	00	00	00	1E	66	21	50	B0	51	00	1B	30
50	40	70	36	00	A0	5A	00	00	00	1E	00	00	00	FD	00	39
60	3F	1F	52	10	00	0A	20	20	20	20	20	20	00	00	00	FC
70	00	4C	47	20	54	56	0A	20	20	20	20	20	20	20	01	43

EDID Block 1, Bytes 128-255 [80H-FFH]

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
00	02	03	37	F1	4E	10	9F	04	13	05	14	03	02	12	20	21
10	22	15	01	26	15	07	50	09	57	07	78	03	0C	00	10	00
20	B8	2D	20	C0	0E	01	4F	3F	FC	08	10	18	10	06	10	16
30	10	28	10	E3	05	03	01	02	3A	80	18	71	38	2D	40	58
40	2C	45	00	A0	5A	00	00	00	1E	01	1D	80	18	71	1C	16
50	20	58	2C	25	00	A0	5A	00	00	00	9E	01	1D	00	72	51
60	D0	1E	20	6E	28	55	00	A0	5A	00	00	00	1E	00	00	00
70	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	11

# HDMI 2(C/S : 9D AA)

EDID Block 0, Bytes 0-127 [00H-7FH]

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
00	00	FF	FF	FF	FF	FF	FF	00	1E	6D	01	00	01	01	01	01
10	01	16	01	03	80	A0	5A	78	0A	EE	91	A3	54	4C	99	26
20	0F	50	54	A1	08	00	31	40	45	40	61	40	71	40	81	80
30	01	01	01	01	01	01	02	3A	80	18	71	38	2D	40	58	2C
40	45	00	A0	5A	00	00	00	1E	66	21	50	B0	51	00	1B	30
50	40	70	36	00	A0	5A	00	00	00	1E	00	00	00	FD	00	39
60	3F	1F	52	10	00	0A	20	20	20	20	20	20	00	00	00	FC
70	00	4C	47	20	54	56	0A	20	20	20	20	20	20	20	01	43

EDID Block 1, Bytes 128-255 [80H-FFH]

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
00	02	03	37	F1	4E	10	9F	04	13	05	14	03	02	12	20	21
10	22	15	01	26	15	07	50	09	57	07	78	03	0C	00	10	00
20	B8	2D	20	C0	0E	01	4F	3F	FC	08	10	18	10	06	10	16
30	10	28	10	E3	05	03	01	02	3A	80	18	71	38	2D	40	58
40	2C	45	00	A0	5A	00	00	00	1E	01	1D	80	18	71	1C	16
50	20	58	2C	25	00	A0	5A	00	00	00	9E	01	1D	00	72	51
60	D0	1E	20	6E	28	55	00	A0	5A	00	00	00	1E	00	00	00
70	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	01

#### # HDMI 3(C/S : 9D 9A)

EDID Block 0, Bytes 0-127 [00H-7FH]

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
00	00	FF	FF	FF	FF	FF	FF	00	1E	6D	01	00	01	01	01	01
10	01	16	01	03	80	A0	5A	78	0A	EE	91	A3	54	4C	99	26
20	0F	50	54	A1	08	00	31	40	45	40	61	40	71	40	81	80
30	01	01	01	01	01	01	02	3A	80	18	71	38	2D	40	58	2C
40	45	00	A0	5A	00	00	00	1E	66	21	50	B0	51	00	1B	30
50	40	70	36	00	A0	5A	00	00	00	1E	00	00	00	FD	00	39
60	3F	1F	52	10	00	0A	20	20	20	20	20	20	00	00	00	FC
70	00	4C	47	20	54	56	0A	20	20	20	20	20	20	01	43	

EDID Block 1, Bytes 128-255 [80H-FFH]

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
00	02	03	37	F1	4E	10	9F	04	13	05	14	03	02	12	20	21
10	22	15	01	26	15	07	50	09	57	07	78	03	0C	00	30	00
20	B8	2D	20	C0	0E	01	4F	3F	FC	08	10	18	10	06	10	16
30	10	28	10	E3	05	03	01	02	3A	80	18	71	38	2D	40	58
40	2C	45	00	A0	5A	00	00	00	1E	01	1D	80	18	71	1C	16
50	20	58	2C	25	00	A0	5A	00	00	00	9E	01	1D	00	72	51
60	D0	1E	20	6E	28	55	00	A0	5A	00	00	00	1E	00	00	00
70	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	F1

#### # HDMI 4(C/S : 9D 8A)

EDID Block 0, Bytes 0-127 [00H-7FH]

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
00	00	FF	FF	FF	FF	FF	FF	00	1E	6D	01	00	01	01	01	01
10	01	16	01	03	80	A0	5A	78	0A	EE	91	A3	54	4C	99	26
20	0F	50	54	A1	08	00	31	40	45	40	61	40	71	40	81	80
30	01	01	01	01	01	01	02	3A	80	18	71	38	2D	40	58	2C
40	45	00	A0	5A	00	00	00	1E	66	21	50	B0	51	00	1B	30
50	40	70	36	00	A0	5A	00	00	00	1E	00	00	00	FD	00	39
60	3F	1F	52	10	00	0A	20	20	20	20	20	20	00	00	00	FC
70	00	4C	47	20	54	56	0A	20	20	20	20	20	20	01	43	

EDID Block 1, Bytes 128-255 [80H-FFH]

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
00	02	03	37	F1	4E	10	9F	04	13	05	14	03	02	12	20	21
10	22	15	01	26	15	07	50	09	57	07	78	03	0C	00	40	00
20	B8	2D	20	C0	0E	01	4F	3F	FC	08	10	18	10	06	10	16
30	10	28	10	E3	05	03	01	02	3A	80	18	71	38	2D	40	58
40	2C	45	00	A0	5A	00	00	00	1E	01	1D	80	18	71	1C	16
50	20	58	2C	25	00	A0	5A	00	00	00	9E	01	1D	00	72	51
60	D0	1E	20	6E	28	55	00	A0	5A	00	00	00	1E	00	00	00
70	00	00	00	00	00	00	00	00	00	00	00	00	00	00	00	E1

#### # RGB(C/S : 97)

	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
00	00	FF	FF	FF	FF	FF	FF	00	1E	6D	01	00	01	01	01	01
10	01	16	01	03	80	A0	5A	78	0A	EE	91	A3	54	4C	99	26
20	0F	50	54	A1	08	00	31	40	45	40	61	40	71	40	81	80
30	01	01	01	01	01	01	02	3A	80	18	71	38	2D	40	58	2C
40	45	00	A0	5A	00	00	00	1E	66	21	50	B0	51	00	1B	30
50	40	70	36	00	A0	5A	00	00	00	1E	00	00	00	FD	00	3A
60	3E	1E	53	10	00	0A	20	20	20	20	20	20	00	00	00	FC
70	00	4C	47	20	54	56	0A	20	20	20	20	20	20	20	00	5C

## 4.2. White Balance Adjustment

### 4.2.1. Overview


#### W/B adj. Objective & How-it-works

- (1) Objective: To reduce each Panel's W/B deviation
- (2) How-it-works : When R/G/B gain in the OSD is at 192, it means the panel is at its Full Dynamic Range. In order to prevent saturation of Full Dynamic range and data, one of R/G/B is fixed at 192, and the other two is lowered to find the desired value.
- (3) Adjustment condition : normal temperature
  - 1) Surrounding Temperature : 25 °C ± 5 °C
  - 2) Warm-up time: About 5 Min
  - 3) Surrounding Humidity : 20 % ~ 80 %

### 4.2.2. Equipment

- (1) Color Analyzer: CA-210 (LED Module : CH 14)
  - (2) Adjustment Computer(During auto adj., RS-232C protocol is needed)
  - (3) Adjustment Remote control
  - (4) Video Signal Generator MSPG-925F 720p/216-Gray (Model: 217, Pattern: 78)
    - Only when internal pattern is not available
- Color Analyzer Matrix should be calibrated using CS-1000.

### 4.2.3. Equipment connection MAP



### 4.2.4. Adj. Command (Protocol)

<Command Format>

START	6E	A	50	A	LEN	A	03	A	CMD	A	00	A	VAL	A	CS	STOP
-------	----	---	----	---	-----	---	----	---	-----	---	----	---	-----	---	----	------

- LEN: Number of Data Byte to be sent
  - CMD: Command
  - VAL: FOS Data value
  - CS: Checksum of sent data
  - A: Acknowledge
- Ex) [Send: JA\_00\_DD] / [Ack: A\_00\_okDDX]

#### RS-232C Command used during auto-adjustment.

RS-232C COMMAND [CMD ID DATA]			Explanation
wb	00	00	Begin White Balance adjustment
wb	00	10	Gain adjustment(internal white pattern)
wb	00	1f	Gain adjustment completed
wb	00	20	Offset adjustment(internal white pattern)
wb	00	2f	Offset adjustment completed
wb	00	ff	End White Balance adjustment (internal pattern disappears )

Ex) wb 00 00 → Begin white balance auto-adj.  
 wb 00 10 → Gain adj.  
 ja 00 ff → Adj. data  
 jb 00 c0  
 ...  
 ...  
 wb 00 1f → Gain adj. completed  
 \*(wb 00 20(Start), wb 00 2f(end)) → Off-set adj.  
 wb 00 ff → End white balance auto-adj.

#### ▪ Adj. Map

	Adj. item	Command (lower caseASCII)		Data Range (Hex.)		Default (Decimal)
		CMD1	CMD2	MIN	MAX	
Cool	R Gain	j	g	00	C0	
	G Gain	j	h	00	C0	
	B Gain	j	i	00	C0	
	R Cut					
	G Cut					
	B Cut					
Medium	R Gain	j	a	00	C0	
	G Gain	j	b	00	C0	
	B Gain	j	c	00	C0	
	R Cut					
	G Cut					
	B Cut					
Warm	R Gain	j	d	00	C0	
	G Gain	j	e	00	C0	
	B Gain	j	f	00	C0	
	R Cut					
	G Cut					
	B Cut					

#### 4.2.5. Adj. method

##### (1) Auto adj. method

- 1) Set TV in adj. mode using POWER ON key.
  - 2) Zero calibrate probe then place it on the center of the Display.
  - 3) Connect Cable.(RS-232C to USB)
  - 4) Select mode in adj. Program and begin adj.
  - 5) When adj. is complete (OK Sign), check adj. status pre mode. (Warm, Medium, Cool)
  - 6) Remove probe and RS-232C cable to complete adj.
- W/B Adj. must begin as start command "wb 00 00", and finish as end command "wb 00 ff", and Adj. offset if need.

##### (2) Manual adjustment. method

- 1) Set TV in Adj. mode using POWER ON.
- 2) Zero Calibrate the probe of Color Analyzer, then place it on the center of LCD module within 10 cm of the surface.
- 3) Press ADJ key → EZ adjust using adj. R/C → 7. White-Balance then press the cursor to the right(key ► ).  
(When right key(►) is pressed 216 Gray internal pattern will be displayed)
- 4) One of R Gain / G Gain / B Gain should be fixed at 192, and the rest will be lowered to meet the desired value.
- 5) Adjustment is performed in COOL, MEDIUM, WARM 3 modes of color temperature.
  - If internal pattern is not available, use RF input. In EZ Adj. menu 7.White Balance, you can select one of 2 Test-pattern: ON, OFF. Default is inner(ON). By selecting OFF, you can adjust using RF signal in 216 Gray pattern.

#### ▪ Adjustment condition and cautionary items

- 1) Lighting condition in surrounding area  
Surrounding lighting should be lower 10 lux. Try to isolate adj. area into dark surrounding.
- 2) Probe location  
: Color Analyzer(CA-210) probe should be within 10 cm and perpendicular of the module surface (80° ~ 100°)
- 3) Aging time  
- After Aging Start, Keep the Power ON status during 5 Minutes.  
- In case of LCD, Back-light on should be checked using no signal or Full-white pattern.

#### 4.2.6. Reference (White balance Adj. coordinate and color temperature)

- Luminance : 216 Gray
- Standard color coordinate and temperature using CS-1000 (over 26 inch)

Mode	Coordinate		Temp	Δuv
	x	y		
Cool	0.269	0.273	13000 K	0.0000
Medium	0.285	0.293	9300 K	0.0000
Warm	0.313	0.329	6500 K	0.0000

- Standard color coordinate and temperature using CA-210(CH 18)

Mode	Coordinate		Temp	Δuv
	x	y		
Cool	0.269 ± 0.002	0.273 ± 0.002	13000 K	0.0000
Medium	0.285 ± 0.002	0.293 ± 0.002	9300 K	0.0000
Warm	0.313 ± 0.002	0.329 ± 0.002	6500K	0.0000

#### 4.2.7. ALELF & EDGE LED White balance table

- EDGE LED module change color coordinate because of aging time.
- Apply under the color coordinate table, for compensated aging time.
- 72LM950V-ZA


GP4	Aging time (Min)	Cool		Medium		Warm	
		X	y	x	y	x	y
		269	273	285	293	313	329
1	0-2	280	287	296	307	320	337
2	3-5	279	285	295	305	319	335
3	6-9	277	284	293	304	317	334
4	10-19	276	283	292	303	316	333
5	20-35	274	280	290	300	314	330
6	36-49	272	277	288	297	312	327
7	50-79	271	275	287	295	311	325
8	80-119	270	274	286	294	310	324
9	Over 120	269	273	285	293	309	323

### 4.3. EYE-Q function check

- (1) Turn on TV.
- (2) Press EYE key of Adjustment remote control.




- (3) Cover the Eye Q II sensor on the front of the using your hand and wait for 6 seconds.



- (4) Confirm that R/G/B value is lower than 10 of the "Raw Data (Sensor data, Back light)". If after 6 seconds, R/G/B value is not lower than 10, replace Eye Q II sensor.



- (5) Remove your hand from the Eye Q II sensor and wait for 6 seconds.




- (6) Confirm that "ok" pop up. If change is not seen, replace Eye Q II sensor.



### 4.4. Local Dimming Function Check

- Step 1) Turn on TV.
- Step 2) At the Local Dimming mode, module Edge Backlight moving right to left Back light of IOP module moving.
- Step 3) Confirm the Local Dimming mode.
- Step 4) Press "exit" key.



### 4.5. Magic Motion Remote control test

- (1) Equipment : RF Remote control for test, IR-KEY-Code Remote control for test
- (2) You must confirm the battery power of RF-Remote control before test(recommend that change the battery per every lot)
- (3) Sequence (test)
  - 1) if you select the "Start(Mute)" key on the Adjustment remote control, you can pairing with the TV SET.
  - 2) You can check the cursor on the TV Screen, when select the "OK" key on the Adjustment remote control.
  - 3) You must remove the pairing with the TV Set by select "OK" key + "Mute" key on the Adjustment remote control for 5 seconds.

### 4.6. 3D function test

- (Pattern Generator MSHG-600, MSPG-6100[Support HDMI1.4])
- \* HDMI mode NO. 872 , pattern No.83

- (1) Please input 3D test pattern like below.



- (2) When 3D OSD appear automatically, then select OK key.



- (3) Don't wear a 3D Glasses, check the picture like below.






#### 4.7. Wi-Fi Test

Step 1) Turn on TV


Step 2) Select Network Connection option in Network Menu.



Step 3) Select Start Connection button in Network Connection.



Step 4) If the system finds any AP like blow PIC, it is working well.



#### 4.8. LNB voltage and 22KHz tone check

(only for DVB-S/S2 model)

##### ▪ Test method


- (1) Set TV in Adj. mode using POWER ON.
- (2) Connect cable between satellite ANT and test JIG.
- (3) Press Yellow key(ETC+SWAP) in Adj Remote control to make LNB on.
- (4) Check LED light 'ON' at 18 V menu.
- (5) Check LED light 'ON' at 22 KHz tone menu.
- (6) Press Blue key(ETC+PIP INPUT) in Adj Remote control to make LNB off.
- (7) Check LED light 'OFF' at 18 V menu.
- (8) Check LED light 'OFF' at 22 KHz tone menu.

##### ▪ Test result

- (1) After press LNB On key, '18 V LED' and '22 KHz tone LED' should be ON.
- (2) After press LNB OFF key, '18 V LED' and '22 KHz tone LED' should be OFF.

#### 4.9. Inspection of light scattering

##### ▪ Test Method



- (1) Push "Power only" key.
- (2) Push "HDMI" hot key.
- (3) Inspect whether light scattering is occurred in internal black pattern or not.
- (4) Push "Power only" key.

#### 4.10. Option selection per country

##### 4.10.1. Overview


- Option selection is only done for models in Non-EU

##### 4.10.2. Method

- (1) Press ADJ key on the Adj. R/C, then select Country Group Menu
- (2) Depending on destination, select Country Group Code 04 or Country Group EU then on the lower Country option, select US, CA, MX. Selection is done using +, - or ►◀ key.

#### 4.11. MHL Test

- (1) Turn on TV
- (2) Select HDMI4 mode using input Menu.
- (3) Set MHL Zig(M1S0D3617) using MHL input, output and power cord.
- (4) Connect HDMI cable between MHL Zig and HDMI4 port.
- (5) Check LED light of Zig and Module of Set.



Result) If, The LED light is green and The Module shows normal stream → OK, Else → NG

## 5. Tool Option selection

- Method : Press "ADJ" key on the Adjustment remote control, then select Tool option.

## 6. Ship-out mode check(In-stop)

- After final inspection, press "IN-STOP" key of the Adjustment remote control and check that the unit goes to Stand-by mode.

## 7. GND and Internal Pressure check

### 7.1. Method

- GND & Internal Pressure auto-check preparation
  - Check that Power cord is fully inserted to the SET.  
(If loose, re-insert)
- Perform GND & Internal Pressure auto-check
  - Unit fully inserted Power cord, Antenna cable and A/V arrive to the auto-check process.
  - Connect D-terminal to AV JACK TESTER
  - Auto CONTROLLER(GWS103-4) ON
  - Perform GND TEST
  - If NG, Buzzer will sound to inform the operator.
  - If OK, changeover to I/P check automatically.  
(Remove CORD, A/V form AV JACK BOX.)
  - Perform I/P test
  - If NG, Buzzer will sound to inform the operator.
  - If OK, Good lamp will lit up and the stopper will allow the pallet to move on to next process.

### 7.2. Checkpoint

- TEST voltage
  - GND: 1.5 KV / min at 100 mA
  - SIGNAL: 3 KV / min at 100 mA
- TEST time: 1 second
- TEST POINT
  - GND TEST = POWER CORD GND & SIGNAL CABLE METAL GND
  - Internal Pressure TEST = POWER CORD GND & LIVE & NEUTRAL
- LEAKAGE CURRENT: At 0.5 mArms

## 8. Audio


No.	Item	Min	Typ	Max	Unit	Remark
1.	Audio practical max Output, L/R (Distortion=10% max Output)	9.0	10.0	12.0	W	Measurement condition
		8.5	8.9	9.8	Vrms	Auto Volume :Off Audio EQ : Off Clear Voice : Off Virtual Surround:Off
2.	Speaker (8Ω Impedance)		10.0	15.0	W	

Measurement condition:



- RF input: Mono, 1 KHz sine wave signal, 100 % Modulation
- CVBS, Component: 1 KHz sine wave signal 0.5 Vrms
- RGB PC: 1 KHz sine wave signal 0.7 Vrms

## 9. USB S/W Download(Service only)

- Put the USB Stick to the USB socket.
- Automatically detecting update file in USB Stick.
  - If your downloaded program version in USB Stick is Low, it didn't work. But your downloaded version is High, USB data is automatically detecting.(Download Version High & Power only mode, Set is automatically Download)
- Show the message "Copying files from memory".



- Updating is starting.
- Updating Completed, The TV will restart automatically.



- If your TV is turned on, check your updated version and Tool option. (explain the Tool option, next stage)
- \* If downloading version is more high than your TV have, TV can lost all channel data. In this case, you have to channel recover. if all channel data is cleared, you didn't have a DTV/ ATV test on production line.


\* After downloading, have to adjust Tool Option again.

- Push "IN-START" key in service remote control.
- Select "Tool Option 1" and push "OK" key.
- Punch in the number. (Each model has their number)

# EXPLODED VIEW


## IMPORTANT SAFETY NOTICE

Many electrical and mechanical parts in this chassis have special safety-related characteristics. These parts are identified by  $\Delta$  in the Schematic Diagram and EXPLODED VIEW. It is essential that these special safety parts should be replaced with the same components as recommended in this manual to prevent X-RADIATION, Shock, Fire, or other Hazards. Do not modify the original design without permission of manufacturer.




## System Configuration

## Clock for LG1152



```
PLL SET[1:0] ==> Internal Pull-UP. N.C is high
00 : CPU clock(1056Mhz), Main0,1/2 DDR (792/792 Mhz)
01 : CPU clock(792Mhz), Main0,1/2 DDR (672/792 Mhz)
10 : CPU clock(1152Mhz), Main0,1/2 DDR (792/672 Mhz)
11 : CPU clock(984Mhz), Main0,1/2 DDR (792/792 Mhz)
```





```

BOOT MODE
*11* or *01* : NOR
*10* : eMMC
*00* : NAND

```

## JTAG I/F FOR MAIN



	NO <sub>m</sub> FRC	SoC internal FRC	LG FRC3	URSA5
MODEL_OPT=0	0	0	1	1
MODEL_OPT=1	0	1	0	1

		HIGH	LOW
MODEL_OPT_2		FHD	UD
MODEL_OPT_3		OPTIC	NON_OPTIC
MODEL_OPT_4	3D DEPTH	3D_Depth_IC	NON_3D_Depth
MODEL_OPT_5	DDR	Reserved	DDR_Default
MODEL_OPT_6	CP BOX	Enable	Disable
MODEL_OPT_7	T2 Tuner	Support	Not Support
MODEL_OPT_8	S Tuner	Support	Not Support
MODEL_OPT_9	C Tuner	Support	Not Support
MODEL_OPT_10	Zoran FRC	Support	Not Support


MODEL OPTION 8 is just for CP Box  
It should not be applied at MP

SECRET





LG Electronics




## NVRAM





## Place to LVDS Wafer






## I2C PULL UP




( for DiVA(China)



IC100  
LG1152D-B1



















Debug




Place near Jack side

MODEL	LG1152 B1	DATE	
BLOCK	MAIN & GPIO	SHEET	1 /

IC101  
LG1152AN-B2



IC100  
LG1152D-B1



⚠

LG Electronics




BLOCK

MAIN POWER




| SHEET

3





















SECRET  
LGElectronics



MODEL		DATE	
BLOCK		SHEET	/





THE  SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FILRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURES SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE  SYMBOL MARK OF THE SCHEMATIC.


SECRET  
LGElectronics




MODEL	LG1152	DATE	
BLOCK	POWER	SHEET	/

## Renesas MICOM


For Debug



## GP4 High/MID Power SEQUENCE





## MICOM MODEL OPTION

MICOM MODEL OPTION

	0	1	
MODEL_OPT_0	NON DIVA	DIVA	For China
MODEL_OPT_1	NON JAPAN	JAPAN	For JAPAN
MODEL_OPT_2	TACT_KEY	TOUCH_KEY	
MODEL_OPT_3	LCD / OLED	PDP	
MODEL_OPT_4	IR Wafer 12/15Pin (GP3_Soft touch)	IR Wafer 10Pin (GP4_TOOL)	For Sample Set
MODEL_OPT_5	NON_MHL	MHL	GP4_HIGH
MODEL_OPT_6	NON_GED	GED	


## Eye Sensor Option

MODEL_OPT_2 \ MODEL_OPT_4	0	1
0	N/A	MC8101_A0V0 (TACT_KEY)
1	CM3231_CAPCELLA (QP3 Soft touch)	CM3231_CAPCELLA (QP4 Soft touch)




THE  SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FILRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURES SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE  SYMBOL MARK OF THE SCHEMATIC.

SECRET




LG Electronics





MODEL		DATE	2011.11.21
BLOCK	MICOM	SHEET	30 /



# RGB / PC AUDIO / SPDIF




THE  SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FILRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURES SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE  SYMBOL MARK OF THE SCHEMATIC.

SECRET  
LGElectronics

 LG ELECTRONICS

MODEL	JACK HIGH / MID	DATE	2011.11.21
BLOCK		SHEET	36 /





ESD for MTK

VA3700-11  
5.0V  
ESD\_MTK\_HP\_OUT

ESD for LG1152

VA3700-12  
5.0V  
ESD\_LG1152\_HP\_OUT






THE  SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FILRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURES SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE  SYMBOL MARK OF THE SCHEMATIC.



SECRET

LGElectronics



MODEL	JACK_COMMON	DATE	2011.11.21
BLOCK		SHEET	37 /




THE  SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FIRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURES SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE  SYMBOL MARK OF THE SCHEMATIC.

SECRET  
LGElectronics

LG Electronics



MODEL	JACK_COMMON	DATE	2011.11.21
BLOCK		SHEET	38 /



ESD for MTK

D4105-\*1  
ADUC 20S 02 010L  
ESD\_MTK

D4106-\*1  
ADUC 20S 02 010L  
ESD\_MTK

D4100-\*1  
5.6V 200pF  
ADMC 5M 02 200L  
ESD\_MTK

D4101-\*1  
5.6V 200pF  
ADMC 5M 02 200L  
ESD\_MTK

D4104-\*1  
5.6V 200pF  
ADMC 5M 02 200L  
ESD\_MTK

ESD for LG1152

D4100-\*2  
5.6V 200pF  
ADMC 5M 02 200L  
ESD\_LG1152

D4101-\*2  
5.6V 200pF  
ADMC 5M 02 200L  
ESD\_LG1152


D4104-\*2  
5.6V 200pF  
ADMC 5M 02 200L  
ESD\_LG1152

THE SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FILRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURES SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE SYMBOL MARK OF THE SCHEMATIC.

SECRET  
LGElectronics




MODEL	IR / KEY	DATE	2011.11.21
BLOCK		SHEET	41 /



MODEL	USB3_HUB	DATE	2011.06.13
BLOCK		SHEET	42 /



+5V\_USB FOR USB1






THE SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FILRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURES SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE SYMBOL MARK OF THE SCHEMATIC.

SECRET  
LGElectronics



MODEL	USB3_HUB_WiFi	DATE	2011.10.26
BLOCK		SHEET	43




THE  SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FILRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURES SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE  SYMBOL MARK OF THE SCHEMATIC.



SECRET  
LGElectronics



MODEL	SCART GENDER	DATE	2011.10.26
BLOCK		SHEET	46 /

ZigBee\_Radio Pulse M\_REMOTE OPTION




THE  SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FILRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURES SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE  SYMBOL MARK OF THE SCHEMATIC.

SECRET  
LGElectronics




MODEL	MOTION REMOTE	DATE	2011.11.21
BLOCK		SHEET	48 /


# Ethernet Block




ESD for MTK




D5000-\*1  
ESD\_MTK  
ADUC 58 02 0R5L



D5001-\*1  
ESD\_MTK  
ADUC 58 02 0R5L




D5002-\*1  
ESD\_MTK  
ADUC 58 02 0R5L




D5003-\*1  
ESD\_MTK  
ADUC 58 02 0R5L


ESD for LG1152




RSD\_LG1152  
D5000-\*2  
5.5V  
ADUC 58 02 0R5L





RSD\_LG1152  
D5001-\*2  
5.5V  
ADUC 58 02 0R5L



RSD\_LG1152  
D5002-\*2  
5.5V  
ADUC 58 02 0R5L



RSD\_LG1152  
D5003-\*2  
5.5V  
ADUC 58 02 0R5L

THE  SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FILRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURES SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE  SYMBOL MARK OF THE SCHEMATIC.


SECRET

LGElectronics



MODEL	LAN_VERTICAL	DATE	2011.11.23
BLOCK		SHEET	50 /

# Ethernet Block






THE ⚠ SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FILRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURES SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE ⚠ SYMBOL MARK OF THE SCHEMATIC.

SECRET  
LGElectronics



MODEL	LG1152 A0	DATE	
PORT	ETHERNET	SHEET	14 / 50




THE  SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FILRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURES SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE  SYMBOL MARK OF THE SCHEMATIC.


SECRET  
LGElectronics



 LG ELECTRONICS

MODEL	AMP_NEO	DATE	2011.11.21
BLOCK		SHEET	54 /



# WOOFER AMP .




THE  SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FILRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURES SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE  SYMBOL MARK OF THE SCHEMATIC.


SECRET  
LGElectronics





MODEL		DATE	
BLOCK		SHEET	/



[ SCART AUDIO MUTE ]




THE  SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FILRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURES SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE  SYMBOL MARK OF THE SCHEMATIC.

SECRET  
LGElectronics



MODEL	SCART AUDIO AMP	DATE	2011.11.21
BLOCK		SHEET	60 /







Option FOR MTK

C6210-\*1  
1uF  
25V  
CI\_MTK

Option FOR LG1152


THE  SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FILRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURES SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE  SYMBOL MARK OF THE SCHEMATIC.



SECRET  
LGElectronics



MODEL	CI SLOT	DATE	2011.10.31
BLOCK		SHEET	62 /

# EARPHONE AMP



THE  SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FIRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURES SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE  SYMBOL MARK OF THE SCHEMATIC.


SECRET



LG Electronics



MODEL	HEADPHONE AMP	DATE	2011.06.29
BLOCK		SHEET	61 /

## T/C/S &amp; H/NIM &amp; T2/C TUNER(EU &amp; CHINA)



THE  SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FILRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURES SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE  SYMBOL MARK OF THE SCHEMATIC.


SECRET  
G Electronics



MODEL	TUNER	DATE	2011.11.21
BLACK		SHEET	65 /

(Option:LNB)

Input	trace widths should be sized to conduct at least 3A
Ouput	trace widths should be sized to conduct at least 2A




SECRET



---

LG Electronics



MODEL	LNB	DATE	2011.11.21
BLOCK		SHEET	69 /






THE  SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FILRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURES SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE  SYMBOL MARK OF THE SCHEMATIC.

SECRET  
LGElectronics



MODEL	LG1152 A0	DATE	
BLOCK	Interface block	SHEET	72 / 100




THE  SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FILRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURES SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE  SYMBOL MARK OF THE SCHEMATIC.

SECRET  
LGElectronics



MODEL	LOCAL DIMMING	DATE	2011.11.21
BLOCK		SHEET	76 /

# eMMC I/F




THE SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FILRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURES SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE SYMBOL MARK OF THE SCHEMATIC.

SECRET  
LGElectronics



MODEL	eMMC	DATE	11.09.29
BLOCK		SHEET	81






SECRET  
LGElectronics



Copyright © 2012 LG Electronics, Inc. All rights reserved.  
Only for training and service purposes






THE  SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FILTRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURES SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE  SYMBOL MARK OF THE SCHEMATIC.




SECRET  
LGElectronics






MODEL	LG1152 B0	DATE	2011. 11. 28
BLOCK	3D Depth	SHEET	/





DDR0 PHY VREF




THE  SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FILRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURES SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE  SYMBOL MARK OF THE SCHEMATIC.

SECRET	 LG ELECTRONICS	MODEL	LG1132 DDR3	DATE	2011. 06 .28
		BLOCK	LG1132 DDR3	SHEET	/

### 3D-Depth Analog for 2.5V



LG1152 for 1.0V



\* \*NON UD Model

```
LG1132  DDR = 668Mhz
LG1152  1.0V ==> IC2306
LG1132  1.0V ==> IC2306
```

\* \*UD Model

```


LG1132  DDR = 792Mhz
LG1152  1.0V ==> IC2501
LG1132  1.1V ==> IC2306



```

L9 CORE for 1.0V

(UD Model only / LG1132 DDR=792Mh)

READY



THE  SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FIRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURES SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE  SYMBOL MARK OF THE SCHEMATIC.






SECRET

---



LG Electronics



MODEL	LG1132 Power	DATE	2011. 06. 28
BLOCK	LG1132 POWER	SHEET	/



MOTOR SENSOR OPTION


THE  SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FILRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURES SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE  SYMBOL MARK OF THE SCHEMATIC.



SECRET  
LGElectronics




MODEL	GP4	DATE	2011.07.01
BLOCK	MOTOR CONTROL	SHEET	/

IR BLASTER




THE  SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FILRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFATURES SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE  SYMBOL MARK OF THE SCHEMATIC.

SECRET  
LGElectronics




MODEL	LG1152 A1	DATE	2011. 06. 02
BLOCK	IR Blaster/Boost	SHEET	94 /







RESET Input  
1) From Main SOC  
2) From SW Switch  
3) SPI\_FLASH Mode / Download Mode to Flash Mem

IC100 outputs being level control via external resistor








GP10[1:10]  
1) Local Dimming Debugging  
2) GP10[1] : 120Hz Mode -> 60 or 120Hz (Programmable)  
240Hz Mode -> 120 or 240Hz (Programmable)  
3) GP10[4] : 120Hz Mode -> 60 or 120Hz (Programmable)  
240Hz Mode -> 120 or 240Hz (Programmable)  
4) GP10[5] : 120Hz Mode -> 120 or 240Hz (Programmable)  
240Hz Mode -> 240 or 480Hz (Programmable)  
5) GP10[6] : 120Hz Mode -> 120Hz (Fixed)  
240Hz Mode -> 240Hz (Fixed)  
6) GP10[7] : 120Hz Mode -> 120Hz (Fixed)  
240Hz Mode -> 240Hz (Fixed)  
7) GP10[8] : External Vsync Input for Local Dimming block  
8) GP10[9] : F-Mode L/R Sync Monitor (AR)  
9) GP10[10] : F-Mode L/R Sync Monitor (AR)  
10) GP10[11] : F-Mode L/R Sync Monitor (AR)  
11) GP10[12] : F-Mode L/R Sync Monitor (AR)  
12) GP10[13] : F-Mode L/R Sync Monitor (AR)  
13) GP10[14] : F-Mode L/R Sync Monitor (AR)  
14) GP10[15] : F-Mode L/R Sync Monitor (AR)  
15) GP10[16] : F-Mode L/R Sync Monitor (AR)  
16) GP10[17] : F-Mode L/R Sync Monitor (AR)  
17) GP10[18] : F-Mode L/R Sync Monitor (AR)  
18) GP10[19] : F-Mode L/R Sync Monitor (AR)  
19) GP10[20] : F-Mode L/R Sync Monitor (AR)  
20) GP10[21] : F-Mode L/R Sync Monitor (AR)  
21) GP10[22] : F-Mode L/R Sync Monitor (AR)  
22) GP10[23] : F-Mode L/R Sync Monitor (AR)  
23) GP10[24] : F-Mode L/R Sync Monitor (AR)  
24) GP10[25] : F-Mode L/R Sync Monitor (AR)  
25) GP10[26] : F-Mode L/R Sync Monitor (AR)  
26) GP10[27] : F-Mode L/R Sync Monitor (AR)  
27) GP10[28] : F-Mode L/R Sync Monitor (AR)  
28) GP10[29] : F-Mode L/R Sync Monitor (AR)  
29) GP10[30] : F-Mode L/R Sync Monitor (AR)  
30) GP10[31] : F-Mode L/R Sync Monitor (AR)



GP10 NO.	OPTION NAME	HIGH	LOW
11	FRAME_OPT	240Hz	120Hz
12	VDD_OPT	With/Out_TCON	With_TCON
13	SDC_OPT	L/R (LG1122)	W/R
14	IMAGE_OPT	IMAGE_NORMAL	IMAGE_OPT (for NOR_T220C)
15	DISPLAY_OPT	OLED	LCD
16	L/DIMMING_OPT	L/D_OR_FRC	L/D_OR_MAIN
17	OPT_READY_1	OPT	Default
18	OPT_READY_2	OPT	Default



All of OPT decaps must be placed on PCB Bottom side






THE SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FILRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVING IF IS ESSENTIAL THAT ONLY MANUFACTURES SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE SYMBOL MARK OF THE SCHEMATIC.

SECRET  
LGElectronics

LG ELECTRONICS

MODEL	240Hz Back-End Board	DATE	2011. 07. 05
BLOCK	FRC-III (LG1122)	SHEET	1 / 6








THE  SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FILTRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURES SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE  SYMBOL MARK OF THE SCHEMATIC.

SECRET  
LGElectronics



MODEL	240Hz Back-End Board	DATE	2011. 07. 05
BLOCK	LG1122_DDR3	SHEET	2 / 6





THE SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FILRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURES SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE SYMBOL MARK OF THE SCHEMATIC.

**SECRET**  
**LG Electronics**



MODEL	120Hz Back-End Board	DATE	2011. 07. 05
BLOCK	POWER	SHEET	3 / 6






SECRET




LGE Internal Use Only


[PMIC Block]




[GPM Block]





PANEL\_POWER



[P-Gamma Block]



THE  SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FILRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURES SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE  SYMBOL MARK OF THE SCHEMATIC.




SECRET  
LGElectronics

 LG ELECTRONICS

MODEL	240Hz Back-End Board	DATE	2011. 07. 05
BLOCK	PMIC / GAMMA / GPM	SHEET	5 / 6



## [80P mini-LVDS output wafer]

## [ 51P HS-LVDS input wafer]



[RIGHT FFC CONNECTOR]

[LEFT FFC CONNECTOR]


THE  SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FILRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFACTURES SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE  SYMBOL MARK OF THE SCHEMATIC.



SECRET  
LG Electronics




MODEL	240Hz Back-End Board	DATE	2011. 07. 05
BLOCK	Wafer	SHEET	6 / 6

Revision History  
(0) Proto Design



THE  SYMBOL MARK OF THIS SCHEMATIC DIAGRAM INCORPORATES SPECIAL FEATURES IMPORTANT FOR PROTECTION FROM X-RADIATION. FILRE AND ELECTRICAL SHOCK HAZARDS, WHEN SERVICING IF IS ESSENTIAL THAT ONLY MANUFATURES SPECIFIED PARTS BE USED FOR THE CRITICAL COMPONENTS IN THE  SYMBOL MARK OF THE SCHEMATIC.

SECRET  
LGElectronics



MODEL		DATE	
BLOCK		SHEET	/



# **LCD TV Repair Guide**

**`12 years New Models**

**< Applicable Model >**

**XXLM960V-ZB**

**XXLM860V-ZB**

**V : T2/C/S2**

**T : T2/C**


**S : T/C/S2**

**0 : T/C**







# 2 types of LED - Edge

Benefit: More Clear More Real

LED



## Edge Type w/ Local Dimming



### Feature

Edge LED	Best picture quality + thin TV
Local Dimming	Local dimming depicts more deep black.

### Model

XXLW750T/W/S/G

42inch : H(2) \* V(8) = 16Block  
42inch : H(2) \* V(8) = 16Block  
42inch : H(2) \* V(8) = 16Block

# 2 types of LED - ALEF


Benefit: More Clear More Real

LED




## ALEF Type Local Dimming

BLU  
structure



Local  
Dimming



### Feature

<b>ALEF LED</b>	Best picture quality + thin TV Slimmer depth better picture quality
<b>Local Dimming</b>	Local dimming depicts more deep black.


### Model

XXLM960V


47inch : H(6) \* V(4) = 24Block  
55inch : H(6) \* V(4) = 24Block




XXLM960V-ZB  
XXLM860V-ZB




## XXLM960V-ZB




# Block Diagram



# Jack Interface




# L9 Block diagram







## L9 Block diagram




About 220 internally generated clocks

# Appendix. Block Diagram for Edge/ALEF Backlight



# Interconnection - 1

## XXLM960V-ZB




## [PCBs]

- 1 Main PCB
- 2 LED driver
- 3 WIFI ASSY
- 4 RF MOTION ASSY
- 5 IR Key PCB
- 6 FRC ASSY
- 7 PSU





# Interconnection – sub PCB( XXLM960V Series )



# Contents of LCD TV Standard Repair Process

No.	Error symptom (High category)	Error symptom (Mid category)	Page	Remarks
1	A. Video error	No video/Normal audio	1	
2		No video/No audio	2	
3		Picture broken/ Freezing	3	
4		Color error	4	
5		Vertical/Horizontal bar, residual image, light spot, external device color error	5	
6	B. Power error	No power	6	
7		Off when on, off while viewing, power auto on/off	7	
8	C. Audio error	No audio/Normal video	8	
9		Wrecked audio/discontinuation/noise	9	
10	D. Function error	Remote control & Local switch checking	10	
11		M4 operating checking	11	
12		Wifi operating checking	12	
13		External device recognition error	13	
14	E. Noise	Circuit noise, mechanical noise	14	
15	F. Exterior error	Exterior defect	15	

**First of all, Check whether there is SVC Bulletin in GCSC System for these model.**

LCD TV

Error  
symptom

## A. Video error

Established  
date


2012.01.16

No video/ Normal audio

Revised date

1/15

**First of all, Check whether all of cables between board is inserted properly or not.**  
**(Main B/D↔ Power B/D, LVDS Cable, Speaker Cable, IR B/D Cable,,)**




## ※ Precaution A7 &amp; A3

Always check & record S/W Version and White Balance value before replacing the Main Board

Replace Main Board

Re-enter White Balance value

LCD TV	Error symptom	A. Video error	Established date	2012.01.16	
		No video/ No audio	Revised date		2/15




LCD TV	Error symptom	A. Video error	Established date	2012.01.16	
		Picture broken/ Freezing	Revised date		3/15

### 🔧 A6

#### Check RF Signal level

- . By using Digital signal level meter
- . By using Diagnostics menu on OSD  
( Setting → Set up → Manual Tuning → Check the Signal )
- Signal strength (Normal : over 50%)
- Signal Quality (Normal: over 50%)



LCD TV

Error  
symptom

## A. Video error

Established  
date

2012.01.16

Color error

Revised date

4/15

A9

Check color by input

- External Input
- COMPONENT
- RGB
- HDMI/DVI

Color  
error?

A10

※ Check  
and replace  
Link Cable  
(LVDS) and  
contact  
condition

Color  
error?

Replace Main B/D

Color  
error?

Replace module

End

A12

Check Test pattern

External Input/  
Component  
errorCheck  
external  
device and  
cableExternal device  
/Cable  
normal

Replace Main B/D

Request repair  
for external  
device/cableRGB/  
HDMI/DVI  
errorCheck external  
device and  
cableExternal device  
/Cable  
normal

Replace Main B/D

LCD TV	Error symptom	A. Video error	Established date	2012.01.16	5/15
		Vertical / Horizontal bar, residual image, light spot, external device color error	Revised date		

## Vertical/Horizontal bar, residual image, light spot

## A9

Check color condition by input  
 -External Input  
 -Component  
 -RGB  
 -HDMI/DVI

## A12

Check Test pattern

Screen normal?

Replace module

Check external device connection condition

Normal?

Request repair for external device

## A10

Check and replace Link Cable

Screen normal?

End

Replace Main B/D (adjust VCOM)

For LGD panel

Replace Main B/D

For other panel

Replace Module

Screen normal?

End

## External device screen error-Color error

Check S/W Version

Check version

S/W Upgrade

Normal screen?

End

Check screen condition by input  
 -External Input  
 -Component  
 -RGB  
 -HDMI/DVI

External Input error

Component error

RGB error

HDMI/DVI

Connect other external device and cable  
 (Check normal operation of External Input, Component, RGB and HDMI/DVI by connecting Jig, pattern Generator, Set-top Box etc.)

Connect other external device and cable  
 (Check normal operation of External Input, Component, RGB and HDMI/DVI by connecting Jig, pattern Generator, Set-top Box etc.)

Screen normal?


Replace Main B/D

Request repair for external device

Screen normal?

Replace Main B/D

LCD TV	Error symptom	B. Power error	Established date	2012.01.16	
		No power	Revised date		6/15





## LCD TV

Error  
symptom

## B. Power error


Established  
date

2012.01.16

Off when on, off while viewing, power auto on/off

Revised date


7/15



\* Please refer to the all cases which can be displayed on power off mode.

Status	Power off List	Explanation
Normal	"POWEROFF_REMOTEKEY"	Power off by REMOTE CONTROL
	"POWEROFF_OFFTIMER"	Power off by OFF TIMER
	"POWEROFF_SLEEPTIMER"	Power off by SLEEP TIMER
	"POWEROFF_INSTOP"	Power off by INSTOP KEY
	"POWEROFF_AUTOOFF"	Power off by AUTO OFF
	"POWEROFF_ONTIMER"	Power off by ON TIMER
	"POWEROFF_RS232C"	Power off by RS232C
	"POWEROFF_RESREC"	Power off by Reserved Record
	"POWEROFF_RECEND"	Power off by End of Recording
	"POWEROFF_SWDOWN"	Power off by S/W Download
Abnormal	"POWEROFF_UNKNOWN"	Power off by unknown status except listed case
	"POWEROFF_ABNORMAL1"	Power off by abnormal status except CPU trouble
	"POWEROFF_CPUABNORMAL"	Power off by CPU Abnormal

LCD TV	Error symptom	C. Audio error	Established date	2012.01.16	
		No audio/ Normal video	Revised date		8/15



LCD TV

Error  
symptom

## C. Audio error

Established  
date


2012.01.16

Wrecked audio/ discontinuation/noise

Revised date


9/15

→ abnormal audio/discontinuation/noise is same after “Check input signal” compared to No audio




LCD TV	Error symptom	D. Function error	Established date	2012.01.16	
		Remote control & Local switch checking	Revised date		10/15

## 1. Remote control(R/C) operating error



LCD TV	Error symptom	D. Function error	Established date	2012.01.16	
		M4 operating checking	Revised date		11/15

## 2. M4(Magic Remocon) operating error



LCD TV

Error  
symptom

## D. Function error

Established  
date


2012.01.16

Wifi operating checking


Revised date

12/15


## 3.Wifi operating error



LCD TV	Error symptom	D. Function error	Established date	2012.01.16	
		External device recognition error	Revised date		13/15




LCD TV	Error symptom	E. Noise	Established date	2012.01.16	
		Circuit noise, mechanical noise	Revised date		14/15





LCD TV	Error symptom	F. Exterior defect	Established date	2012.01.16	
		Exterior defect	Revised date		15/15



# Contents of LCD TV Standard Repair Process Detail Technical Manual

No.	Error symptom	Content	Page	Remarks
1	A. Video error_ No video/Normal audio	Check LCD back light with naked eye	A1	
2		LED driver B+ 24V measuring method	A2	
3		Check White Balance value	A3	
4	A. Video error_ No video/Audio	Power Board voltage measuring method	A4	
5	A. Video error_ video error /Video lag/stop	TUNER input signal strength checking method	A6	
6		LCD-TV Version checking method	A7	
7		Tuner Checking Part	A8	
8	A. Video error _Vertical/Horizontal bar, residual image, light spot	LCD TV connection diagram	A9	
9	A. Video error_ Color error	Check Link Cable (LVDS) reconnection condition	A10	
10		Adjustment Test pattern – ADJ Key	A12	
11	<b>&lt;Appendix&gt;</b> Defected Type caused by T-Con/ Inverter/ Module	Exchange T-Con Board (1)	A-1/5	
12		Exchange T-Con Board (2)	A-2/5	
13		Exchange LED driver Board (PSU)	A-3/5	
14		Exchange Module (1)	A-4/5	
15		Exchange Module (2)	A-5/5	

**Continue to the next page**

# Contents of LCD TV Standard Repair Process Detail Technical Manual


Continued from previous page

No.	Error symptom	Content	Page	Remarks
16	B. Power error_ No power	Check front display LED	A17	
17		Check power input Voltage & ST-BY 3.5V	A18	
18		Checking method when power is ON	A19	
19	B. Power error_Off when on, off while viewing	POWER OFF MODE checking method	A22	
20	C. Audio error_ No audio/Normal video	Checking method in menu when there is no audio	A24	
22		Voltage and speaker checking method when there is no audio	A25	
22	D. Function error	Remote controller operation checking method	A27	
23		Motion Remote operation checking method	A28	
24		Wifi operation checking method	A29	

# Standard Repair Process Detail Technical Manual

LCD TV	Error symptom	A. Video error_No video/Normal audio	Established date	2011. 12 .14	
	Content	Check LCD back light with naked eye	Revised date		A1

<XXLM9600>




After turning on the power and disassembling the case, check with the naked eye, whether you can see light from 2 locations.

A1

# Standard Repair Process Detail Technical Manual

LCD TV	Error symptom	A. Video error_No video/Normal audio	Established date	2011. 12 .14	
	Content	LED driver B+ 24V measuring method	Revised date		A2





Check the DC 24V and Inverter on

14 Pin (Power Board ↔ Driver) PSU	
1 ~ 5	24V
6 ~ 10	GND
11	Detect
12	Inverter On/Off
13	Int. PWM
14	Ext. PWM (PDIM)

# Standard Repair Process Detail Technical Manual

LCD TV	Error symptom	A. Video error_No video/Normal audio	Established date	2011. 12 .14	
	Content	Check White Balance value	Revised date		A3

<ALL MODELS>




## Entry method

1. Press the ADJ button on the remote controller for adjustment.
2. Enter into White Balance of item 10.
3. After recording the R, G, B (GAIN, Cut) value of Color Temp (Cool/Medium/Warm), re-enter the value after replacing the MAIN BOARD.

# Standard Repair Process Detail Technical Manual

LCD TV	Error symptom	A. Video error_No video/ Audio	Established date	2011. 12 .14	A4
	Content	Power Board voltage measuring method	Revised date		



Check the DC 24V, 12V, 3.5V.

24 Pin (Power Board ↔ Main Board) – 공통			
SMAW200-H24S (YEONHO)			
1	Power on	2	20V (24V)
3	20V (24V)	4	20V (24V)
5	GND	6	GND
7	GND	8	GND
9	3.5V	10	3.5V
11	3.5V	12	3.5V
13	GND	14	GND
15	GND	16	N.C (Only LPB : V-sync)
17	12V	18	Inverter On/off
19	12V	20	N.C (LPB, Lamp : A-dim)
21	12V	22	PWM Dim #1
23	N.C (only Lamp SCANNING Model : PWM Dim #2)	24	Error-out




# Standard Repair Process Detail Technical Manual

LCD TV	Error symptom	A. Video error_Video error, video lag/stop	Established date	2011. 12 .14	
	Content	TUNER input signal strength checking method	Revised date		A6

<ALL MODELS>



Settings → Set up → Manual Tuning  
→ select channel



When the signal is strong, use the attenuator (-10dB, -15dB, -20dB etc.)



A6




# Standard Repair Process Detail Technical Manual

LCD TV	Error symptom	A. Video error_Video error, video lag/stop	Established date	2011. 12 .14	
	Content	LCD-TV Version checking method	Revised date		A7

<ALL MODELS>

## 1. Checking method for remote controller for adjustment

Version




Press the IN-START with the remote controller for adjustment

# Standard Repair Process Detail Technical Manual

LCD TV	Error symptom	A. Video error_Video error, video lag/stop	Established date	2011. 12 .14	
	Content	TUNER checking part	Revised date		A8

<ALL MODELS>




Checking method:

1. Check the signal strength or check whether the screen is normal when the external device is connected.
2. After measuring each voltage from power supply, finally replace the MAIN BOARD.

# Standard Repair Process Detail Technical Manual

LCD TV	Error symptom	A. Video error _ Vertical/Horizontal bar, residual image, light spot	Established date	2011. 12 .14	
	Content	LCD TV connection diagram (1)	Revised date		A9

<ALL MODELS>





As the part connecting to the external input, check the screen condition by signal



# Standard Repair Process Detail Technical Manual

LCD TV	Error symptom	A. Video error_Color error	Established date	2011. 12 .14	
	Content	Check Link Cable (LVDS) reconnection condition	Revised date		A10

<ALL MODELS>






Check the contact condition of the Link Cable, especially dust or mis insertion.

A10

# Standard Repair Process Detail Technical Manual

LCD TV	Error symptom	A. Video error_Color error	Established date	2011. 12 .14	
	Content	Adjustment Test pattern - ADJ Key	Revised date		A12



You can view 6 types of patterns using the ADJ Key


Checking item : 1. Defective pixel 2. Residual image 3. MODULE error (ADD-BAR,SCAN BAR..)  
4.Video error (Classification of MODULE or Main-B/D!)

**A12**


## Appendix : Exchange T-Con Board (1)



Solder defect, CNT Broken




Solder defect, CNT Broken



Solder defect, CNT Broken




Solder defect, CNT Broken



Solder defect, CNT Broken



Abnormal Power Section



Solder defect, Short/Crack




Abnormal Power Section



Solder defect, Short/Crack



## Appendix : Exchange T-Con Board (2)



Abnormal Power Section



Abnormal Power Section



Solder defect, Short/Crack



Solder defect, Short/Crack



Fuse Open, Abnormal power section




Abnormal Display



GRADATION



Noise



GRADATION

## Appendix : Exchange LED driver Board (PSU)




No Light



Dim Light



Dim Light



Dim Light



No picture/Sound Ok



## Appendix : Exchange the Module (1)




Panel Mura, Light leakage



Panel Mura, Light leakage



Press damage



Crosstalk



Press damage




Crosstalk



Press damage

**Un-repairable Cases**  
**In this case please exchange the module.**

## Appendix : Exchange the Module (2)



Vertical Block  
Source TAB IC Defect



Vertical Line  
Source TAB IC Defect




Vertical Block  
Source TAB IC Defect



Horizontal Block  
Gate TAB IC Defect



Horizontal Block  
Gate TAB IC Defect



Horizontal line  
Gate TAB IC Defect





Horizontal Block  
Gate TAB IC Defect

**Un-repairable Cases**  
**In this case please exchange the module.**

# Standard Repair Process Detail Technical Manual

LCD TV	Error symptom	B. Power error _No power	Established date	2011. 12 .14	
	Content	Check front display LED	Revised date		A17

<XXLM9600>



Front LED control :  
Menu → Option →  
Standby Light  
→ ON/ Off


ST-BY condition: Red or Turn Off  
Power ON condition: Turn Off

A17

# Standard Repair Process Detail Technical Manual

LCD TV	Error symptom	B. Power error _No power	Established date	2011. 12 .14	
	Content	Check power input voltage and ST-BY 3.5V	Revised date		A18

<XXLM9600>



Check the DC 24V, 12V, 3.5V.


24 Pin (Power Board ↔ Main Board) – 공통			
SMAW200-H24S (YEONHO)			
1	Power on	2	20V (24V)
3	20V (24V)	4	20V (24V)
5	GND	6	GND
7	GND	8	GND
9	3.5V	10	3.5V
11	3.5V	12	3.5V
13	GND	14	GND
15	GND	16	N.C (Only LPB : V-sync)
17	12V	18	Inverter On/off
19	12V	20	N.C (LPB, Lamp : A-dim)
21	12V	22	PWM Dim #1
23	N.C (only Lamp SCANNING Model : PWM Dim #2)	24	Error-out

A18

# Standard Repair Process Detail Technical Manual

LCD TV	Error symptom	B. Power error _No power	Established date	2011. 12 .14	A19
	Content	Checking method when power is ON	Revised date		

<XXLM9600>



Check “power on” pin is high

24 Pin (Power Board ↔ Main Board) – 공통			
SMAW200-H24S (YEONHO)			
1	Power on	2	20V (24V)
3	20V (24V)	4	20V (24V)
5	GND	6	GND
7	GND	8	GND
9	3.5V	10	3.5V
11	3.5V	12	3.5V
13	GND	14	GND
15	GND	16	N.C (Only LPB : V-sync)
17	12V	18	Inverter On/off
19	12V	20	N.C (LPB, Lamp : A-dim)
21	12V	22	PWM Dim #1
23	N.C (only Lamp SCANNING Model : PWM Dim #2)	24	Error-out


A19



# Standard Repair Process Detail Technical Manual

LCD TV	Error symptom	B. Power error _Off when on, off whiling viewing	Established date	2011. 12 .14	
	Content	POWER OFF MODE checking method	Revised date		A22

<ALL MODELS>



## Entry method


1. Press the IN-START button of the remote controller for adjustment
2. Check the entry into adjustment item 3

A22

# Standard Repair Process Detail Technical Manual

LCD TV	Error symptom	C. Audio error_No audio/Normal video	Established date	2011. 12 .14	A24
	Content	Checking method in menu when there is no audio	Revised date		

<ALL MODELS>




## Checking method

1. Press the Setting button on the remote controller
2. Select the Sound function of the Menu
3. Select the Sound Setting
4. Select TV Speaker from Off to On


# Standard Repair Process Detail Technical Manual

LCD TV	Error symptom	C. Audio error_No audio/Normal video	Established date	2011. 12 .14	
	Content	Voltage and speaker checking method when there is no audio	Revised date		A25

<XXLM9600>



24 Pin (Power Board ↔ Main Board)			
1	Power on	2	24V
3	24V	4	24V
5	GND	6	GND
7	GND	8	GND
9	3.5V	10	3.5V
11	3.5V	12	3.5V
13	GND	14	GND
15	GND	16	V-sync
17	12V	18	Inverter On/off
19	12V	20	N.C
21	12V	22	PWM Dim #1
23	PWM Dim #2	24	Error-out



## Checking order when there is no audio

- ① Check the contact condition of or 24V connector of Main Board
- ② Measure the 24V input voltage supplied from Power Board  
(If there is no input voltage, remove and check the connector)
- ③ Connect the tester RX1 to the speaker terminal and if you hear the Chik Chik sound when you touch the GND and output terminal, the speaker is normal.




# Standard Repair Process Detail Technical Manual

LCD TV	Error symptom	D. Function error	Established date	2011. 12 .14	
	Content	Remote controller operation checking method	Revised date		A27

<XXLM9600>



①



②

③

④

P4102	
1	SCL
2	SDA
3	GND
4	KEY1
5	KEY2
6	St 3.5V
7	GND
8	GP4 LED R
9	IR
10	GND

## Checking order

- 1, 2. Check IR cable condition between IR & Main board.
3. Check the st-by 3.3V on the terminal 6.
4. When checking the Pre-Amp when the power is in ON condition, it is normal when the Analog Tester needle moves slowly, and defective when it does not move at all.

A27


# Standard Repair Process Detail Technical Manual

LCD TV	Error symptom	D. Function error	Established date	2011. 12 .14	
	Content	Motion Remote operation checking method	Revised date		A28

<XXLM9600>



①



②

③

P4800	
1	3.3V
2	GND
3	RX
4	TX
5	RESET
6	DC
7	DD
8	GND


## Checking order

- 1, 2. Check Motion cable condition between Motion assy & Main board.
3. Check the 3.3V on the terminal 1.


# Standard Repair Process Detail Technical Manual

LCD TV	Error symptom	D. Function error	Established date	2011. 12 .14	
	Content	Wifi operation checking method	Revised date		A29

<XXLM9600>



①



②

③

P4301	
1	VDD
2	DM
3	DP
4	GND

## Checking order

- 1, 2. Check Wifi cable condition between Wifi assy & Main board.
3. Check the 5V on the terminal 1.